THIRD SUPPLEMENT

RECEIVING TUBE SUBSTITUTION GUIDEBOOK

BY

H. A. MIDDLETON



JOHN F. RIDER PUBLISHER, INC. 116 WEST 14th ST., NEW YORK 11, N.Y.

Copyright 1957 by

JOHN F. RIDER PUBLISHER, INC.

All rights reserved. This book or any parts thereof may not be reproduced in any form or in any language without permission of the publisher.

Library of Congress Catalog Card Number 51-1704

Printed in the United States of America

FOREWORD

This Third Supplement to the Receiving Tube Substitution Guidebook, in addition to the original volume and the First and Second Supplements to it, is an accumulation of over 15 years of experience in substituting tubes in radio and television receivers and other electronic equipment. It is a never-ending process which we shall continue in an effort to keep this information as current as possible.

Most of these additional substitutions are for use in television receivers and therefore, because of their critical application in some cases, special consideration should be given your selection when you have a choice of substitutes. A stage-by-stage discussion of the most popular circuits used in television receivers is included in the First Supplement. If there is any question as to whether or not the stage being substituted is a critical one and which characteristics of the substitute should be given special consideration, take a moment to read the article covering the stage in question.

The information herein, in the large part, calls for substitutions only. It is not the object of these instructions to tell you how to improve radios, television receivers and other electronic equipment but rather to help you use the tubes you have, in order to replace those that are not available. Exceptions to the above statements are tubes especially designed as replacements of types where improvement is needed generally or for specific use such as 5881 for 6L6, 5AW4 for 5U4G, 6CU6 for 6BQ6GT, and the same type numbers in ruggedized tubes designated by an additional ending letter, as 6SN7WGT. Types such as these are designed to improve the life of the tube, the efficiency

of the circuit in which they are applied, or both. Characteristics are generally identical to the type they replace. Elements are heavier duty or especially treated in order to withstand greater overloads and construction is more rugged.

Introduced in this Third Supplement is a European-American and American-European tube substitution guide. Due to the recent heavy influx of British and other European electronic equipment, the demand for a substitution guide for these tubes has been increasing steadily. This is due to the fact that in many instances European tubes are not readily available.

Also included in this supplement is a cumulative index indicating the volume and page where the tube you wish to substitute is located.

We have endeavored to list all the practical substitutions. Some, no doubt, have been omitted. When considering substitution, others not listed will likely come to mind. When this happens, write the tube number down immediately in the form used here and attach it in its proper place.

This supplement includes picture tube substitutions. It is recommended that before substitution of picture tube is attempted, a few moments be taken to read over the short article which precedes the picture tube section.

Phoenix, Arizona June 1957

H. A. Middleton

TABLE OF CONTENTS

						PAGE
SECTION 1 -	RECEIVING	TUBE SUBSTITUTIONS		•	•	1
SECTION 2 -	PICTURE T	UBE SUBSTITUTIONS -				
		Substituting Picture Tubes in TV Receivers .		•	•	32
		Picture Tube Substitutions		• , •		34
SECTION 3 -	EUROPEAN	AND AMERICAN SUBSTITUTIONS -				
the Company of the Co		European-American Substitutions				38
		American-European Substitutions		• 1	• •	44
CUMULATIVE	INDICES -					
		Receiving Tubes	• .		• •	51
		Picture Tubes	•	•	•	64
		European Tubes				66

TUBE	SUB.	PERF.	CIRCUIT CHANGES NECESSARY
OB3	1266	E	No changes.
1AB6	1AC6	E	Parallel circuits only. No changes.
1AC5	1AG4	G	Change miniature socket to subminiature socket and rewire as follows: Change pin No. 4 on miniature to F-pin on subminiature. No. 2 to G1 No. 8 to G2 No. 7 to P No. 5 to F +
1AC6	1AB6	E	No changes.
1AE5			No practical substitute.
1AF4	1AJ4	G	No changes.
1AF6			No practical substitute.
1AG4	1AC5	G	Reverse 1AC5 to 1AG4 procedure.
1AG5	1AJ5	G	No changes.
	1AK5	G	No changes.
1AH4	1AK4	\mathbf{E}	No changes.
1AH5			No practical substitute.
1AH6			No practical substitute.
1AJ4	1AF4	G	No changes.
1AJ5	1AG5	G	No changes.
	1AK5	G	No changes.
1AK4	1AH4	E	No changes.
1AK5	1AG5	G	No changes.
	1AJ5	G	No changes.
1AX2	1B3	E E	Change socket to octal and rewire as follows: No. 2 on miniature to No. 2 on octal to 7 No changes.
1B3	2B3	P	No changes.
1C3	1E4	G	Change socket to octal and rewire as follows:
	- LUT		No. 1 on miniature to No. 2 on octal 2 to 3 4 to 5 7 to 7
	1LE3	G	Change socket to octal and rewire as follows: No. 1 on miniature to No. 1 on octal to 2 to 2 to 6 7 to 8
	(Cont.)		

1C3-2BN4 THIRD SUPPLEMENT - RECEIVING TUBE SUBSTITUTION GUIDE

TUBE SU	UB. PE	ERF.	CIRCUIT CHANGES NECESSARY
			Change socket to octal and rewire as follows: No. 1 on miniature to No. 1 on octal to \cdot 2 to \cdot 2 \cdot 0
1D3			No practical substitute.
1E3			No practical substitute.
1E4 10	C3	G	Reverse 1C3 to 1E4 procedure.
11	LE3	G	Rewire as follows: No. 2 pin to No. 1 1000
11	LF3	E	Rewire as follows: No. 2 pin to No. 1 To Solve to Solv
1LE3 10	C3	G	Change socket to miniature and rewire as follows: No. 1 on octal to pin No. 1 on miniature to 2 to 2 to 4 one of to 4 one of to 7
11	E4	E	Rewire as follows: Change No. 1 pin to pin No. 2 to 3 to 5 to 5 to 5 sub
11	LF3	E	No changes.
	E4	G G E	Reverse 1C3 to 1LF3 procedure. Reverse 1E4 to 1LF3 procedure. No changes.
1M3			No practical substitute.
1T2 1	B3	G	Only where space permits, change socket to octal and rewire as follows: No. 1 on subminiature to No. 2 on octal to 7
1:	X2	G	Only where space permits, change socket to nine pin miniature and rewire as follows: No. 1 on subminiature to No. 2 on miniature to 9
1U4 5	910	E	No changes.
1V6			No practical substitute.
2A3 5	930	E	No changes.
2AF4 2	2T4	G	No changes.
2B3 1	.B3	P	No changes.
2B5			No practical substitute.
2BN4			No practical substitute.

TUBE	SUB.	PERF.	CIRCUIT CHANGES NECESSARY
2C22	6J 5	G	Rewire as follows: Plate Cap to pin No. 3 Grid Cap to pin No. 5 Substitute of the control of
2C51	6SN7	G	Parallel circuits only. Rewire as follows: Change pin No. 1 to pin No. 8 on octal 2 to 3 3 to 1 4 to 2 6 to 5 7 to 4 8 to 6 9 to 7
	5670	E	No changes.
2C52	12SL7	G	Parallel circuits only. No changes.
2CB5			No practical substitute.
2D21	2D21W 5727	E E	No changes. No changes.
2D21W	2D21 5727	G E	No changes.
2E22			No practical substitute.
2T4	2AF4	G G	No changes.
2V2			No practical substitute.
3A2	3A3	E	Change socket to octal and rewire as follows: No. 2 on miniature to No. 2 on octal to 7
3A3	3A2	G	Reverse 3A2 to 3A3 procedure. Use only where high voltage
	3B2 3C2	G G	does not exceed 20KV. No changes. No changes.
3AF4			No practical substitute.
3AL5			No practical substitute.
3AU6	3BA6	G	No changes.
	3BC5	G	Rewire as follows: Reverse connections on pin 2 and pin 7.
	3CB6	G	Rewire as follows: Reverse connections on pin 2 and pin 7.
	3BZ6	G	Rewire as follows: Reverse connections on pin 2 and pin 7.
3AV6	3BT6	G	No changes.

3B2-3CB6 THIRD SUPPLEMENT - RECEIVING TUBE SUBSTITUTION GUIDE

TUBE	SUB.	PERF.	CIRCUIT CHANGES NECESSARY
3B2	3A3 3C2		No changes.
3BA6	3AU6	G	No changes.
	3BC5	G	Rewire as follows: Reverse connections on pin No. 2 and pin No. 7.
			Reverse connections on pin No. 2 and pin No. 1
	3BZ6	G	Rewire as follows:
			Reverse connections on pin No. 2 and pin No. 7.
	3CB6	G	Rewire as follows: Reverse connections on pin No. 2 and pin No. 7.
			ORIG O
3BC5	3AU6 3BA6	G G	Reverse 3AU6 to 3BC5 procedure. Reverse 3BA6 to 3BC5 procedure.
	3BZ6 3CB6 3CF6	G G G	No changes. Tie pin No. 2 and No. 7 together. No changes. Tie pin No. 2 and No. 7 together. No changes. Tie pin No. 2 and No. 7 together.
3BE6			No practical substitute.
3BN4			No practical substitute.
3BN6			No practical substitute.
3BT6	3AV6	G	No changes.
3BU8			No practical substitute.
3BY6	3CS6	G	No changes.
3BZ6	3AU6 3BA6 3BC5 3CB6	G G G	Reverse 3AU6 to 3BZ6 procedure. Reverse 3BA6 to 3BZ6 procedure. No changes. No changes.
3C2	3A3 3B2	G G	No changes. No changes.
3C4	3C5	G	Change socket to octal and rewire as follows: No. 1 on miniature to No. 2 on octal
			10 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1
	3Q4	G	Rewire as follows: Change pin No. 3 to pin No. 4 to 50 to 3
	3V4	G	No changes.
3C5	3C4	G	Parallel circuits only. Reverse 3C4 to 3C5 procedure.
3CB6	3AU6 3BA6 3BC5 3BZ6	G G G	Reverse 3AU6 to 3CB6 procedure. Reverse 3BA6 to 3CB6 procedure. No changes. No changes.

TUBE	SUB.	PERF.	CIRCUIT CHANGES NECESSARY
3CE5	3CB6 3CF6	E E	No changes. No changes.
3CF6	3BC5	G	No changes.
	3BZ6	Ğ	No changes.
	3CB6	G	No changes.
	3CE5	E	No changes.
3CS6	3BY6	G	No changes.
3DT6			No practical substitute.
3Q4	3C4	G	Parallel circuits only. Reverse 3C4 to 3Q4 procedure.
	3Q5	G	Change socket to octal and rewire as follows:
			Change pin No. 1 on miniature to pin No. 2 on octal to 3
			60 1 1 1 1 1 1 1 1 1 1
			(0, 0) 5 to 8 $(0, 0)$
			$\bigcirc \bigcirc $
			ORIG 7 to 7
354	3C4	G	Parallel circuits only. Rewire as follows:
			Change pin No. 3 to pin No. 6
			(0 0) 4 to 3 (0 0) 6 to 2 (0 0)
	3Q5	G	Change socket to octal and rewire as follows:
			Change pin No. 1 on miniature to pin No. 2 on octal
			$ \begin{array}{cccccccccccccccccccccccccccccccccccc$
			$\bigcirc \bigcirc $
			7 to 3 sus
3V4	3C4	G	Parallel circuits only. No changes.
	905		
	3Q 5	G	Change socket to octal and rewire as follows: Change pin No. 1 on miniature to pin No. 2 on octal
			Change pin No. 1 on miniature to pin No. 2 on octal to 3
8 ³ .			60 to 4
			(0 0) 5 to 8 (0°0)
			6 to 5 to 7
			onic 7 to 7
	3S4	G	Rewire as follows:
			Change pin No. 3 to pin No. 4 to 2
4BC5	4CB6	G	No cnanges. Tie pin No. 2 and pin No. 7 together.
4BC8	4BK7	G	No changes.
	4BQ7	Ğ	No changes.
	4BS8	Ğ	No changes.
	4BZ7	G	No changes.
	4BZ8	G	No changes.
	4CX7	G	No changes. Pins No. 8 and No. 9 are connected internally together.
4BK7	4BC8	G	No changes.
	4BQ7	G	No changes.
	4BS8	G	No changes.
	4BZ8 4CX7	G	No changes.
	TOAT	G	No changes. Pins No. 8 and No. 9 are connected internally together.
ADME			
4BN6			No practical substitute.

4BQ7-4CX7 THIRD SUPPLEMENT - RECEIVING TUBE SUBSTITUTION GUIDE

TUBE	SUB.	PERF.	CIRCUIT CHANGES NECESSARY	
4BQ7	4BC8	G	No changes.	
	4BK7	G	No changes.	
	4BS8	G	No changes.	
	4BZ7	G	No changes.	
	4BZ8	G	No changes.	
	4CX7	G	No changes. Pins No. 8 and No. 9 are connected together internally.	
4BS8	4BC8	G	No changes.	
	4BK7	G	No changes.	
	4BQ7	G	No changes.	
	4BZ8	G	No changes.	
	4CX7	G	No changes. Pins No. 8 and No. 9 are connected together internally.	
4BU8			No practical substitute.	
4BX8	4BC8	G	No changes.	
	4BK7	G	No changes.	
	4BQ7	G	No changes.	
	4BS8	G	No changes.	
	4BZ8	G G	No changes. Pins No. 8 and No. 9 are connected	
	4CX7	Gara.	together internally.	
4BZ7	4BC8	G	No changes.	
	4BK7	G	No changes.	
	4BQ7	G	No changes.	
	4BS8	G	No changes.	
	4BZ8 4CX7	G G	No changes. Remove and tape any wires anchored on	pin No. 9.
4BZ8	4BC8	G	No changes.	
	4BK7	G	No changes.	
	4BQ7	G	No changes.	
	4BS8	G	No changes.	nin No 0
	4CX7	G	No changes. Remove and tape any wires anchored on	pm No. 3.
4CB6	4BC5	G	No changes.	
4CX7	4BC8	G	Rewire as follows: Tie pins No. 8 and No. 9 together.	
			11e pins No. 8 and No. 5 together.	
				(000)
				(6 (6)
			ORIG	
	4BK7	G	Rewire as follows: Tie pins No. 8 and No. 9 together.	300
			The philis No. 8 and No. 9 together.	
				(000)
			()	(6)
			기념 <mark>, prie</mark> 모임하는 사일 보는 하는 학자 가게 하시는 사이지를 보고 있다.	
	4BQ7	G	Rewire as follows:	SUB
			Tie pins No., 8 and No. 9 together.	
				600
				(Q Q)
			ORIG	
	4B\$8	G	Rewire as follows:	SUB
			Tie pins No. 8 and No. 9 together.	
				60
			()	ക്രഹയ്
				(6 , 6)
			그 경기 - ORIG : 그리고 그 그 그 그 그 그 그 그 그 그 그 그 그 그 그 그 그 그	SUB
	4BZ8	G	Rewire as follows:	
			Tie pins No. 8 and No. 9 together.	
			(O)	(OO)
				(Q Q)

	0.220	DDD -	<u> </u>
TUBE	SUB.	PERF.	CIRCUIT CHANGES NECESSARY
4DT6			No practical substitute.
5AM8	5AS8	G	Reverse 5AS8 to 5AM8 procedure.
5AN8	5AV8	E	Rewire as follows: Reverse connections on pins No. 1 and No. 3. Change pin No. 6 to pin No. 9 7 to 8 8 to 6 9 to 7
	5U8	G	Rewire as follows:
			Change pin No. 2 to pin No. 9 3 to 8 7 to 3 8 to 2 9 to 7
5AQ5	5V6	G	Change socket to octal and rewire as follows: No. 1 on miniature to No. 5 on octal to 8 3 to 2 0 0 4 to 7 5 to 3 6 to 4 10 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0
5AS4	5AU4 5AW4 5U4GA 5U4GB 5V3 5931	G G G E E	No changes. If transformer will stand 1.5 amperes more. No changes. No changes. No changes. No changes. No changes.
5AS8	5AM8	G	Rewire as follows: Change pin No. 1 to pin No. 3 3 to 1 6 to 8 7 to 9 8 to 7 8 to 7 9 to 6
5AU4	5AS4 5AW4 5R4GY 5T4 5U4G 5U4GA 5U4GB 5V3 5931	GE G G G E E E E	No changes.
5AV8	5AN8 5U8	E G	Reverse 5AN8 to 5AV8 procedure. Rewire as follows: Change pin No. 1 to pin No. 8 2 to 9 3 to 1 6 to 2 7 to 7 8 to 3 sub Office 9 to 6
5AW4	5AS4 5AU4 5R4GY 5T4 5U4G 5U4GA 5U4GB 5V3 5931	GEGGGEEEE	No changes.

5AX4-5U4GA

THIRD SUPPLEMENT - RECEIVING TUBE SUBSTITUTION GUIDE

TUBE	SUB.	PERF.	CIRCUIT CHANGES NECESSARY
5AX4	5AS4 5AW4 5T4 5U4G 5U4GA 5U4GB 5X3 5V4 5931	EEGGEEEE	No changes. No changes. If transformer will stand 1.2 amperes more. No changes. No changes.
5AZ4	5 AX4 5 V 4 5 Y 3 5 Y 4	E E G	No changes. No changes. No changes. Rewire as follows: Change pin No. 2 to pin No. 7
			4 to 3 6 to 5
	5Z4	E	No changes.
5B8			No practical substitute.
5BE8			No practical substitute.
5BK7	5BQ7	G	No changes.
ODK.	5BZ7	Ğ	No changes.
5BR8			No practical substitute.
5BT8			No practical substitute.
5CG8			No practical substitute.
5CL8			No practical substitute.
5CM8			No practical substitute.
5J6			No practical substitute.
5T4	5AS4 5AW4 5R4 5U4 5U4GA 5U4GB 5V4 5931	ਜ ਜ ਜ ਜ ਜ ਜ ਜ ਜ ਜ ਜ ਜ ਜ ਜ ਜ ਜ ਜ ਜ ਜ ਜ ਜ	No changes.
5 T 8			No practical substitute.
5U4G	5AS4 5AW4 5U4GA 5U4GB 5V3 5931	E E E E E	No changes.
5U4GA	5AS4 5AU4 5AW4 5R4GY 5T4 5U4G 5U4GB 5V3 5931	8888888888	No changes. No changes. If transformer will stand 1.5 amperes more. No changes.

TUBE	SUB.	PERF.	CIRCUIT CHANGES NECESSARY
5U4GB	5AS4	E	No changes.
	5AU4	E	No changes.
17	5AW4	E	No changes.
	5R4GT	G	No changes.
	5T4	E	No changes.
	5U4G	G	No changes.
	5U4GA 5V3	E	No changes.
	5931	E E	No changes. No changes.
	0301	E	No changes.
5U8	5AN8 5AV8	G G	Reverse 5AN8 to 5U8 procedure.
	DAVO	ď	Reverse 5AV8 to 5U8 procedure.
5V3	5AS4	G	No changes.
	5AU4	E	No changes.
	5AW4	G	No changes.
	5U4GB	G	No changes.
P374	2004		
5V4	5931	G	No changes.
5V6	EAOE	E.	Demons 5405 to 5770 and the
340	5AQ5	E.	Reverse 5AQ5 to 5V6 procedure.
5W4	5 Z 4	E	No changes.
01	5931	Ğ	No changes.
	0001		140 Changes.
5X8	5AT8	E	Same as 6AT8 to 6X8 procedure.
5 Y 3	5AZ4	E	No changes.
	5Y3WGT	E	No changes.
	5Z4	E	No changes.
	5931	G	No changes.
5Y4	5AZ4	E	Downers EATA to EWA manadama
014	5Z4	Ē	Reverse 5AZ4 to 5Y4 procedure. No changes.
	5931	Ğ	No changes.
	0001	-	140 Ontering CD
5 Z 4	5AZ4	E	No changes.
	5V4	G	No changes.
	5W4	G	No changes.
	5Y3	E	No changes.
	5Y4	E	No changes.
	5931	G	No changes.
6AB8			No practical substitute.
			110 practical adaptitute:
6AC7	6006	G	Parallel circuits only. No changes.
	6134	E	No changes.
6AD8			No practical substitute.
CATE			
6AE7			No practical substitute.
6AF4	3AF4	E	Donallal atautte anim Toutall Fraha Frankling to the State of the Stat
UAP 4	3AF4	r.	Parallel circuits only. Install 7-ohm 5-watt resistor in series with the filament.
	6T4	G	No changes.
	V-1	u	no changes.
6AG5	6186	E	No changes.
6AH6	6485	E	No changes.
6AK4	6C4	G	Whore and a manufact
UI	UCT	G	Where space permits: Pin No. 1 to pin No. 6
			\sim
			5 to 7 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0
			8 to 5 & 1 sue
0477			
6AK5	6AK5W	E	No changes.
	5591 5654	E	No changes.
	5654	E	No changes.
	6096	E	No changes.

6AL5-6AU4

THIRD SUPPLEMENT - RECEIVING TUBE SUBSTITUTION GUIDE

TUBE	SUB.	PERF.	CIRCUIT CHANGES NECESSARY
6AL5	3AL5	E	Parallel circuits only. Install 5-ohm 5-watt resistor in series with the filament.
	6AL5W	E	No changes.
	5726	E	No changes.
	6058	E	No changes.
	6097	Ē	No changes.
	6663	$\widetilde{\mathbf{E}}$	No changes.
6AL6	6BJ5 6BS5	G G	Parallel circuits only. Reverse 6BJ5 to 6AL6 procedure. Reverse 6BS5 to 6AL6 procedure.
	GOOO	ď	neverse ond to oand procedure.
6AM6	6064	E	No changes.
04340	5 4 340	17	Develor since it and a Tractall O. E. about E. world register in gories with
6AM8	5AM8	E	Parallel circuits only. Install 2.5-ohm 5-watt resistor in series with the filament.
	6AS8	G	Change pin No. 1 to pin No. 3
	0.120		3 to 1
			6 to 9
			(2 2) 7 to 8 (5 (6)
			(b) 0 8 to 6
			ORIG 9 to 7
6AN8	5AN8	E	Parallel circuits only. Install 2.5-ohm 5-watt resistor in series with
OVINO	DAMO	E	filament.
	6AW8	G	Rewire as follows:
			Change pin No. 1 to pin No. 3
			3 to 1
			6 to 9
			(6, 6) 7 to 8
			8 to 7
			oric 9 to 6
6AQ4			No practical substitute.
CAOE	CACEW	To.	No abourge
6AQ5	6AQ5W 6CM6	E E	No changes. Reverse 6CM6 to 6AQ5 procedure.
	6005	E	No changes.
	6669	Ğ	No changes.
			지수 하는 그 이 가는 사람들이 되었다. 폭제관 독해 그런 그는 사이에 되어 그렇게 되었다. 그리고 나를
6AQ6	6066	E	Parallel circuits only. No changes.
6AR8			No practical substitute.
021110			110 precious substracts
6AS6	6AS6W	E	No changes.
	5725	E	No changes.
6AS7	5998	G	Parallel circuits only. No changes.
02101	6080	Ĕ	No changes.
		o de la companya da la companya da La companya da la co	The state of the s
6AS8	5AM8	G	Parallel circuits only. Install 2.5-ohm 5-watt resistor in series with
	6AM8	G	filament and use same procedure as 5AM8 to 6AS8. Reverse 6AM8 to 6AS8 procedure.
	OAMO		the verse driving to drive procedure.
6AT6	6066	E	No changes.
O A TOO	r A TOO	E	Parallel circuits only. Install 2.5-ohm 5-watt resistor in series with
6AT8	5AT8		filament.
	6BR8	G	Connect pins No. 8 and No. 3 together.
	6X8	E	Rewire as follows:
			Change pin No. 1 to pin No. 2
			$\begin{array}{cccccccccccccccccccccccccccccccccccc$
			3 to 6 6 to 9
			6 to 9 (5° 6) 7 to 8
			9 to 7
			가 있는 경향 경하는 이 사람들은 사람들이 되었다. 하는 것은 사람들은 사람들은 사람들이 되었다. 사람들은 사람들은 사람들은 사람들은 사람들은 사람들은 사람들은 사람들은
6AU4	6AX4	G	No changes.
	6BL4	Ğ	No changes, where space permits.
	(Cont.)		

(Cont.)

TUBE	SUB.	PERF.	CIRCUIT CHANGES NECESSARY
6AU4 (Cont.)	6U3	G	Change socket to miniature and rewire as follows: No. 3 on octal to pin No. 3 on miniature
	6V3	G	Change socket to miniature and rewire as follows: No. 3 on octal to cap on miniature to pin No. 2 and 7 to 4 to 5 8 to 5
	6W4	G	No changes.
6AU6	3AU6	E	Parallel circuits only. Install 5-ohm 5-watt resistor in series with
	4AU6	E	filament. Paralel circuits only. Install 5-ohm 5-watt resistor in series with
	6AU6WA 5749 6136	E G E	filament. No changes. No changes. No changes.
6AU8	6AW8 6BA8 6BH8 6U8	G G G G	No changes. No changes. No changes. Parallel circuits only. Rewire as follows: Change pin No. 1 to pin No. 8 2 to 9 3 to 1 6 to 7 7 to 2 8 to 3 9 to 6
6AV4	6BX4 6W5	G E	No changes. Change socket to octal and rewire as follows: No. 1 on miniature to pin No. 3 on octal to 7 to 7 to 2 forms fo
	6X4 6X5	G G	No changes. Same as 6AV4 to 6W5 procedure.
6AV6	3AV6 6066	E G	Parallel circuits only. Install 5-ohm 5-watt resistor in series with filament. No changes.
6AW8	6AN8 6AU8	G G	Parallel circuits only. Reverse 6AN8 to 6AW8 procedure. No changes.
6AX4	6AU4 6BL4	G G	No changes.
6AX5	6BW4	G	Reverse 6BW4 to 6AX5 procedure.
6AX8	6U8	G	No changes.
6AZ8			No practical substitute.
6BA6	3BA6 6BA6W 6DA6 5749 6136	E G E G	Parallel circuits only. Install 5-ohm 5-watt resistor in series with filament. No changes. Reverse 6DA6 to 6BA6 procedure. No changes. No changes.

6BA8-6BH5 THIRD SUPPLEMENT - RECEIVING TUBE SUBSTITUTION GUIDE

mere			
TUBE	SUB.	PERF.	CIRCUIT CHANGES NECESSARY
6BA8	6AU8	G	No changes.
	6AW8	G	No changes.
	6BH8	G	No changes.
6BC4	6AJ4	G	Rewire as follows:
			Change pin No. 1 to pin No. 5
			$\frac{2}{2}$ to $\frac{3}{2}$
			5 to 8
			$\begin{pmatrix} \mathbf{b} & \mathbf{b} \end{pmatrix}$ 6 $\mathbf{t} \hat{0}$ 2 $\begin{pmatrix} \mathbf{b} & \mathbf{b} \end{pmatrix}$
			7 to $\overline{3}$ 0
			one 8 to 3
			9 to 5
6BC5	3BC5	E	Parallel circuits only. Install 5-ohm 5-watt resistor in series with
			filament.
en co	4DC0	1 771	Danillal almoster anima Teretall O.F. almost most annual in acutan mith
6BC8	4BC8	E	Parallel circuits only. Install 3.5-ohm 5-watt resistor in series with filament.
	5BC8	E	Parallel circuits only. Install 1.5-ohm 5-watt resistor in series with
			filament.
	6BK7	G	No changes.
	6BQ7 6BS8	G	No changes.
	6BZ7	G E	No changes. No changes.
	6BZ8	Ğ	No changes.
	X155	G	No changes.
6BD4A	6BK4	E	No changes.
6BD6	6DA6	G	Reverse 6DA6 to 6BD6 procedure.
000	5749	Ğ	No changes.
6BE6	3BE6	E	Parallel circuits only. Install 5-ohm 5-watt resistor in series with
			filament.
	6BY6	G	No changes.
	5750	E	No changes.
6BE7			No practical substitute.
6BE8	5BE8	E	Parallel circuits only. Install 1.5-ohm 5-watt resistor in series with filament.
	6U8	E	Rewire as follows:
			Change pin No. 1 to pin No. 9
			$\begin{array}{cccccccccccccccccccccccccccccccccccc$
			$ \begin{array}{cccccccccccccccccccccccccccccccccccc$
			7 to 7
			8 to 7
			9 to 2
6BG6	6DN6	G	No changes.
6BH5	6BD6	G	Change socket to miniature and rewire as follows:
			Change pin No. 1 to pin No. 6 on miniature.
		104	$ \begin{array}{cccccccccccccccccccccccccccccccccccc$
			(0 0) 4 to 3 $(0 0)$
			$\begin{array}{cccccccccccccccccccccccccccccccccccc$
			6 to 5 3 to 7
	6BJ6	G	Change socket to miniature and rewire as follows:
	(Cont.)		Change pin No. 1 to pin No. 6 on miniature.
	(Cont.)		2 to 1
			$ \begin{array}{cccccccccccccccccccccccccccccccccccc$
			$ \begin{pmatrix} 0 & 0 \\ 0 & 0 \end{pmatrix} \qquad \qquad$
			6 to 5
			3 to 2

TUBE	SUB.	PERF.	CIRCUIT CHANGES NECESSARY
6BH5	6DA6	G	Rewire as follows:
(Cont.)			Change pin No. 1 to pin No. 8
(Com.)			6000
			(b) (b) 6 to 7 (b) (d)
	6SS7	G	Parallel circuits only. Change socket to octal and rewire as follows:
	0001		Change pin No. 1 to pin No. 6 on octal
			2 to 4
			3 to 3
			(6, 6) 4 to 2 (6)
			5 to 7 6 to 8
			3 to 5
6BH6	6065	G	Parallel circuits only. Reverse 6065 to 6BH6 procedure.
	6265	E	No changes.
	6661	E	No changes.
6BH8	6AU8	G	No changes.
	6AW8	Ğ	No changes.
	6BA8	G	No changes.
0D 75		-	
6BJ5	6AL6	G	Change socket to octal and rewire as follows:
			Change pin No. 1 to pin No. 5 on octal to 8
			60 3 to 2
			$\begin{pmatrix} 0 & 0 \\ 0 & 0 \end{pmatrix}$ 4 to 7
			$\circ \circ $
			orig 7 to 4 sus
	6M5	G	Change miniature socket to noval and rewire as follows: Change pin No. 1 to pin No. 2
			2 to 3
			600
			(0, 0) 4 to 5 $(0, 0)$
			5 to 7 7 to 1
			1 LO I SUB
6BJ6	6DA6	G	Reverse 6DA6 to 6BJ6 procedure.
	6662	E	No changes.
OD TO			No. 11. 14. 14. 14. 14. 14. 14. 14. 14. 14
6BJ7			No practical substitute.
6BJ8	6BN8	G ·	No changes.
0200	02110	_	110 Olimingon
6BK4	6BD4-A	E	No changes.
		· · · · · · · · · · · · · · · · · · ·	
6BK6	6066	G	No changes.
6BK7	5BK7	E	Parallel circuits only. Install 2.6-ohm 5-watt resistor in series with
ODIC	ODIL	. 😐 . 🗸	filament.
	6BC8	G	No changes.
	6BQ7	G	No changes.
	6BS8	G	No changes.
	6BZ7	G	No changes.
	6BZ8 X155	G G	No changes. No changes.
	7770	ď	140 Changes.
6BL4	6AU4-GTA	G	No changes.
	6AX4	P	No changes.
CDN4	ODN4	E7	Dorallol airavita only Install C.O. short world resistant in series with
6BN4	2BN4	E	Parallel circuits only. Install 6.8-ohm 5-watt resistor in series with filament.
	3BN4	E	Parallel circuits only. Install 7-ohm 5-watt resistor in series with
			filament.
6BN5			No practical substitute.
6BN6	3BN6	E	Parallel circuits only. Install 5-ohm 5-watt resistor in series with
ONIG	оид	E .	filament.
	(Cont.)		A CAMPANA A CAMP

6BN6-6BS7

THIRD SUPPLEMENT - RECEIVING TUBE SUBSTITUTION GUIDE

TUBE	SUB.	PERF.	CIRCUIT CHANGES NECESSARY
6BN6 (Cont.)	4BN6	E	Parallel circuits only. Install 5-ohm 5-watt resistor in series with filament.
			그림 바다 내내 내내는 그 아니는 아니는 그는 그를 먹는데 되었다.
6BN8	6BJ8	G	No changes.
6BQ6	6DQ6	E	No changes.
6BQ7	4BQ7	E	Parallel circuits only. Install 4-ohm 5-watt resistor in series with filament.
	5BQ7,	E	Parallel circuits only. Install 2-ohm 5-watt resistor in series with filament.
	6BC8	G	No changes.
	6BK7	G	No changes.
	6BS8	G	No changes.
	6BZ7	G	No changes.
	6BZ8	G	No changes.
	X155	G	No changes.
6BR7	6BS7 6C6	E G	Reverse 6BS7 to 6BR7 procedure. Parallel circuits only. Change socket to six pin socket and rewire as follows:
			Change pin No. 2 to grid cap
			3 to No. 5
			\mathfrak{A}^{0} 4 to 1 \mathfrak{A}^{0}
			(b) (c) 5 to 6
			0 0 7 to 2 0 0
			one 8 to 3 sub
			9 to 4
	6 J 7	G	Parallel circuits only. Change socket to octal and rewire as follows:
			Change pin No. 2 to grid cap on octal
			3 to No. 8
			600 4 to 2 600
			0 0 7 to 3
			onic 8 to 4 sub
			9 to 5
	6W7	G	Same as 6BR7 to 6J7 procedure.
	7C7	G	Change socket to octal and rewire as follows: Change pin No. 2 to pin No. 6 on octal
			4 to 1 5 to 8
			(0,0) 7 to 2 $(0,0)$
			8 to 3
			9 to 4
6BR8	5BR8	E	Parallel circuits only. Install 3-ohm 5-watt resistor in series with filament.
6BS5	6AL6	G	Change socket to octal and rewire as follows: Change pin No. 1 to pin No. 5 on octal
			2 to 5
			3 to 8 (00)
			4 to 2 5 to 7
			$\frac{1}{1}$ or 1
			이번 그리고 있다면 하는 사람들은 사람들은 사람들은 사람들은 사람들은 사람들이 되었다.
6BS7	6BR7	E	Rewire as follows: Change grid cap on 6BS7 to pin No. 2.
	cae	G .	Change socket to six pin.
	6C6		Change pin No. 3 to pin No. 5
	(Cont.)		4 to 1
			$ \begin{array}{cccccccccccccccccccccccccccccccccccc$
			5 to 8 (0 0) 8 to 3
			9 to 4
			7 to 2
			기존 그 사람들이 하느라 하는 사람들은 학교 본 선생들은 그는 선생이가 들었다.

TUBE	SUB.	PERF.	CIRCUIT CHANGES NECESSARY
6BS7 (Cont.)	6 J7	G	Parallel circuits only. Change socket to octal and rewire as follows: Change pin No. 3 to pin No. 8 on octal
			4 to 2 5 to 7
			(0,0) 7 to 3 $(0,0)$
			(a) 8 to 4 (b) 6
			onic 9 to 5 sub
	6W7	G	Same as 6BS7 to 6J7 procedure.
	7C7	G	Change socket to loctal and rewire as follows: Change pin No. 3 to pin No. 7 on octal
			4 to 1 5 to 8
			8 to 3
			ORIG 9 to 4
6BS8	4BS8	E	Parallel circuits only. Install 3.5-ohm 5-watt resistor in series with
			filament.
	5BS8	E	Parallel circuits only. Install 1.5-ohm 5-watt resistor in series with the filament.
	6BC8	G	No changes.
	6BK7	Ğ	No changes.
	6BQ7	Ē	No changes.
	6BZ7	G	No changes,
	6BZ8	G	No changes.
	X155	G	No changes.
6BT6	6066	E	No changes.
6BT8	5BT8	E	Parallel circuits only. Install 2.5-ohm 5-watt resistor in series with filament.
6BU5			No practical substitute.
6BU8	3BU8	E	Parallel circuits only. Install 5-ohm 5-watt resistor in series with filament.
	4BU8	E	Parallel circuits only. Install 5-ohm 5-watt resistor in series with
			filament.
6BV7			No practical substitute.
6BV8			No practical substitute.
6BW4	6AX5	E	Change socket to octal and rewire as follows:
			Change pin No. 1 to No. 5 on octal
			4 to 2 5 to 7
			9 to 8 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0
	6V4	G	Rewire as follows:
	044	ď	Change pin No. 9 to pin No. 3
			600 change pin No. 5 to pin No. 5
			one one of the second of the s
	7Z4	E	Change socket to loctal and rewire as follows:
			Change pin No. 1 to pin No. 6 on octal
			4 to 1 5 to 0
			5 to 8 (0.00)
			$ \begin{array}{cccccccccccccccccccccccccccccccccccc$
6BW7	6BX6	G	No changes.
	JUAU		ATV VALUMADUDA

6BX4-6CA5

THIRD SUPPLEMENT - RECEIVING TUBE SUBSTITUTION GUIDE

TUBE	SUB.	PERF.	CIRCUIT CHANGES NECESSARY
6BX4	6AX5	E	Parallel circuits only. Change socket to octal and rewire as follows: Change pin No. 1 to pin No. 3 on octal
			3 to 7
			4 to 2
			\(\tilde{Q} \) \(\tilde{Q} \
			ORIG SUB
	CATTA	~	Don'llel circuite only. No changes
	6AV4	G	Parallel circuits only. No changes.
	6X4	G	No changes.
	6X5	G	Same as 6BX4 to 6AX5.
6BX6	6BN7	G	No changes.
6BX8	4BX8	E	Parallel circuits only. Install 3.5-ohm 5-watt resistor in series with
		2.0	filament.
	6BC8	G	No changes.
	6BE6	G	No changes.
	6BK7	G G	No changes.
	6BQ7	G	No changes.
	6BS8	Ğ	No changes.
~	6BZ7	Ğ	No changes.
	6BZ8	G	No changes.
	X155	G	No changes.
07770			
6BY6	3BY6	E	Parallel circuits only. Install 5-ohm 5-watt resistor in series with
			filament.
	6CS6	G	No changes.
	5915	G	No changes.
6BY8			No practical substitute.
6BZ6	3BZ6	E	Parallel circuits only. Install 5-ohm 5-watt resistor in series with
			filament.
	4BZ6	E	Parallel circuits only. Install 4.7-ohm 5-watt resistor in series with
•			filament.
	6CB6	${f E}$	No changes.
	6DE6	E	No changes.
		and the second	
6BZ7	4BZ7	E	Parallel circuits only. Install 2.5-ohm 5-watt resistor in series with
			filament.
	5BZ7	E	Parallel circuits only. Install 1.5-ohm 5-watt resistor in series with
	0.5.2.		filament.
	6BC8	G	No changes.
	6BK7	Ğ	No changes.
	6BQ8	E	No changes.
	6BS8	G	No changes.
	6BZ8	E	No changes.
	X155	E	No changes.
6BZ8	4BZ8	E	Parallel circuits only. Install 3.5-ohm 5-watt resistor in series with
			filament.
	6BC8	G	No changes.
	6BK7	Ğ	No changes.
	6BS8	Ğ	No changes.
	6BZ7		No changes.
		G	
	X155	E	No changes.
601	5610	~	No shangag
6C4	5610	G	No changes.
	6135	E	No changes.
6C6	6BR7	G	Parallel circuits only. Reverse 6BR7 to 6C6 procedure.
	0.5101		I manifest delicated delication d
6CA5	7A5	G	Parallel circuits only. Change socket to octal and rewire as follows:
			Change pin No. 1 to pin No. 7 on octal
			2 to 6
			60 3 to 1 60
			$ \begin{array}{cccccccccccccccccccccccccccccccccccc$
			6 to 3 sub 7 to 2
			į W 2

TUTTO TO	CITTO	DEDE	OTT CTTTE CTT A VANCE AND THE
TUBE	SUB.	PERF.	CIRCUIT CHANGES NECESSARY
6CA7	6L6	G	Parallel circuits only. No changes.
6CB5	6BG6	P	Rewire as follows:
			Change pin No. 1 to pin No. 8 4 to 5
			ORIG
	6CD6	P	Same as 6CB5 to 6BG6 procedure.
6CB6	6BZ6	G	No changes.
	6DC6 6DE6	G E	No changes. No changes.
6CD6	CDNC		
OCDO	6DN6	E	No changes.
6CD7			No practical substitute.
6CE5	3CE5	E	Parallel circuits only. Install 5-ohm 5-watt resistor in series with
	4CE5	E	filament.
		ь	Parallel circuits only. Install 4.7-ohm 5-watt resistor in series with filament.
	6BZ6 6CB6	G E	Same as 6CE5 to 6CB6 procedure. Rewire as follows:
			Connect pin No. 7 to pin No. 2
	6DE6	E	Same as 6CE5 to 6CB6 procedure.
6CG7	6BL7	E	Same as 6CG7 to 6SN7 procedure.
	6BX7	G	Parallel circuits only. Same as 6CG7 to 6SN7 procedure.
	6SN7	E	Change socket to octal and rewire as follows:
			Change pin No. 1 to pin No. 2 on octal 2 to 1
			3 to 3
			4 to 8 600 5 to 7
			6 to 5 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0
			7 to 4 SUB 8 to 6
	12AU7	G	Parallel circuits only. Rewire as follows:
		-	Reverse wires connected to No. 5 and No. 9
6CG8	5CG8	E	Parallel circuits only. Install 2.5-ohm 5-watt resistor in series with
	CATTO	~	filament.
	6AT8	G	Rewire as follows: Connect pin No. 8 to pin No. 3
	evo	~	
	6X8	G	Rewire as follows: No. 1 to No. 2
			2 to 3
			(C) (D) 6 to 9 (C) (C) (C)
			7 to 8 00
			8 to 6 Sub 9 to 7
6CH6	6132	E	No changes.
6CH7	6BC8 6BK7	G G	Tie pin No. 8 and No. 9 together. Tie pin No. 8 and No. 9 together.
	6BQ7	G	Tie pin No. 8 and No. 9 together.
	6BS8 6BZ7	G E	Tie pin No. 8 and No. 9 together. Tie pin No. 8 and No. 9 together.
	6BZ8	E	Tie pin No. 8 and No. 9 together.
	X155	E	Tie pin No. 8 and No. 9 together.
6CH8			No practical substitute.

6CJ6-6CS5 THIRD SUPPLEMENT - RECEIVING TUBE SUBSTITUTION GUIDE

gwide:	CITO	DEDE	CIDCHIE CHANGES NECESSARY
TUBE	SUB.	PERF.	CIRCUIT CHANGES NECESSARY
6CJ6	6CD6	G	Where space permits. Change socket to octal and rewire as follows: Change pin No. 2 to pin No. 5 on octal
			3 to 3 4 to 2
			0 to 0
			8 to 8 9 to 3 SUB
6CL6	6677	E	No changes.
6CL8	5CL8	E	Parallel circuits only. Install 2.5-ohm 5-watt resistor in series with filament.
6CM6	5CM6	E	Parallel circuits only. Install 2.5-ohm 5-watt resistor in series with
	5V6	E	filament. Parallel circuits only. Install 2.5-ohm 5-watt resistor in series with
			filament. Change socket to octal. Rewire as follows: Change pin No. 1 to pin No. 4 on octal
			3 to 5 4 to 2
			5 to 7
			6 to 5 7 to 8
			9 to 3
	6AQ5		Change socket to miniature and rewire as follows:
	OAQS	G	Change pin No. 1 to pin No. 6 on miniature
			3 to 1 4 to 3
			5 to 4 (0°0)
			6 to 7 7 to 2
			9 to 5
	6V6 6W6	G G	Same as 6CM6 to 5V6 procedure. Parallel circuits only. Same as 6CM6 to 5V6 procedure.
6CM7	6CS7	G	Rewire as follows:
			Change pin No. 3 to pin No. 8
			8 to 3
			ORIG
6СМ8	5CM8	E	Parallel circuits only. Install 2.5-ohm 5-watt resistor in series with the filament.
6CN6			No practical substitute.
6CN7			No practical substitute.
6CQ7			No practical substitute.
6CR6	6SF7	G	Change socket to octal and rewire as follows: Change pin No. 1 to pin No. 3 on octal 2 to 5
			3 to 8
			(0 0) 5 to 6
			(Q 0) 6 to 4 (Q 0)
			ORIG 7 to 2
6CS5	6CU5	G	Reverse 6CU5 to 6CS5 procedure.
	(0.4)		

(Cont.)

TUBE	SUB.	PERF.	CIRCUIT CHANGES NECESSARY
6CS5	6K6	G	Change socket to octal and rewire as follows:
(Cont.)			Change pin No. 1 to pin No. 4 on octal
			2 to 8 3 to 5
			4 to 2
			$0 0 \overline{7} 0 \overline{0} 0$
			6 to 5 0^{4}
			7 to 8 sub 9 to 3
	6V6	G	Same as 6CS5 to 6K6 procedure.
	6W6	E	Same as 6CS5 to 6K6 procedure.
	6Y6	G	Same as 6CS5 to 6K6 procedure.
6CS6	3CS6	E	Parallel circuits only. Install 5-ohm 5-watt resistor in series with
	6BY6	G	filament. No changes.
6CS7			그 그는 사람들은 사람들이 가는 사람들에게 하면 하는 그를 보는 것이 가득하는 것이다. 사람은
	6CM7	G	Reverse 6CM7 to 6CS7 procedure.
6CU5	6CS5	G	Change socket to noval and rewire as follows: Change pin No. 1 to pin No. 2 on noval
			2 to 3
			600 3 to 4
			(a) (b) 4 to 5 (c) (c) (d) (d) (d) (d) (d) (d) (d) (d) (d) (d
			5 to 6 6 6 to 1
			ORIG 7 to 9
	6V6	G	Same as 6CU5 to 6W6 procedure.
	6W6	G	Change socket to octal and rewire as follows:
		~	Change pin No. 1 to pin No. 8 on octal
			2 to 5
			\mathfrak{g}_{0} to 2
			(0 0) 4 to 7 $(0 0)$
			$\begin{array}{cccccccccccccccccccccccccccccccccccc$
	6Y6	G	Same as 6CL5 to 6W6 procedure.
6CU6	6DQ6	\mathbf{E}	No changes.
6CX7	4CX7	E	Parallel circuits only. Install 3.5-ohm 5-watt resistor in series with
			filament.
	6BC8	G	No changes. Tie pin No. 8 and No. 9 together.
	6BK7 6BQ7	G	Same as 6BC8 to 6CX7.
	6BS8	E G	Same as 6BC8 to 6CX7. Same as 6BC8 to 6CX7.
	6BZ7	Ğ	Same as 6BC8 to 6CX7.
	6BZ8	Ğ	Same as 6BC8 to 6CX7.
	X155	G	Same as 6BC8 to 6CX7.
6DA6	6BA6	G	Change socket to miniature and rewire as follows:
			Change pin No. 2 to pin No. 1 on miniature
			$\frac{3}{4}$ to $\frac{7}{2}$
			$ \begin{pmatrix} 0 & 0 & 4 & \text{to} & 3 \\ 0 & 0 & 5 & \text{to} & 4 \end{pmatrix} $
			8 to 6
	6BD6	G	9 to 2
			Same as 6DA6 to 6BA6 procedure.
	6BJ6	G	Parallel circuits only. Change socket to miniature and rewire as follows:
			Change pin No. 2 to pin No. 1 on miniature
			3 to 2 4 to 3
			$ \begin{array}{cccccccccccccccccccccccccccccccccccc$
			7 to 5
			8 to 6
			9 to 7

6DB6-6SJ7 THIRD SUPPLEMENT - RECEIVING TUBE SUBSTITUTION GUIDE

TUBE	SUB.	PERF.	CIRCUIT CHANGES NECESSARY
6DB6			No practical substitute.
6DC6	6BZ6 6CB6 6DC6	G G G	No changes. No changes. No changes.
6DE6	6BZ6 6CB6 6DE6	G G	No changes. No changes. No changes.
6DG6	6K6 6V6 6W6	G G E	Parallel circuits only. No changes. Parallel circuits only. No changes. No changes.
6DN6	6BG6 6CD6	G E	No changes. No changes.
6DQ6	6BQ6 6CU6	G G	No changes.
6DT6	3DT6	E	Parallel circuits only. Install 5-ohm 5-watt resistor in series with
	4DT6	E	filament. Parallel circuits only. Install 4.7-ohm 5-watt resistor in series with filament.
6F6	1621 1622	E E	No changes. Parallel circuits only. No changes.
6H6	5679	G	Reverse 5679 to 6H6 procedure.
6J4	6J4WA	E	No changes.
6J 5	2C22	G	Reverse 2C22 to 6J5 procedure.
6 J6	5964 6101	E E	No changes. No changes.
6J7	1221 6059 7000	E G G	Reverse 1221 to 6J7 procedure. Reverse 6059 to 6J7 procedure. No changes.
6K6	1621 5871	E G	Parallel circuits only. No changes. No changes.
6K7	5732	E	No changes.
6L6	1621 1622 5881 5932	G G E E	Parallel circuits only. No changes. No changes. No changes. No changes.
	6550	E	No changes.
6M5	6BJ5	G	Reverse 6BJ5 to 6M5 procedure.
6N7	1635	E	Parallel circuits only. No changes.
6Q5	884	E	No changes.
6S7	5732	G	Parallel circuits only. No changes.
6SA7	5961	E	No changes.
6SB7Y	5961	G	No changes.
6SG7	6006	E	No changes.
6SH7	6006	G	No changes.
6SJ7	6SJ7WGT 6006	E G	No changes.

TUBE	SUB.	PERF.	CIRCUIT CHANGES NECESSARY
6SK7	6006 6137	G E	No changes.
6SL7	6SL7WGT 6113	E E	No changes. No changes.
6SN7	6SN7WGT 6180	E E	No changes. No changes.
6SU7	6113	E	No changes.
6T4	3AF4	G	Parallel circuits only. Install 7-ohm 5-watt resistor in series with filament.
	6AF4	G	No changes.
6U3	6AU4	G	Parallel circuits only. Reverse 6AU4 to 6U3 procedure.
6U7	5732	G	No changes.
6U8	6AU8 6AX8	G G	Parallel circuits only. Reverse 6AU8 to 6U8 procedure. No changes.
6V3	6AU4	G	Reverse 6AU4 to 6V3 procedure.
6V4	6BW4	G	Parallel circuits only. Reverse 6BW4 to 6V4 procedure.
6V6	1621 1622 5871 5992	G G E E	Parallel circuits only. No changes. Parallel circuits only. No changes. No changes.
	6061	E	No changes. Reverse 6061 to 6U6 procedure.
6W2	6X2	G	No changes.
6X2	6W2	E	No changes.
6X4	6AV4 6BX4 6X4W 6063 6202	E G E G	Parallel circuits only. No changes. No changes. No changes. No changes. No changes.
6X5	6AV4 6BX4 6X5WGT	G G E	Parallel circuits only. Reverse 6AV4 to 6X5 procedure. Reverse 6BX4 to 6X5 procedure. No changes.
6Y7	1635	E	No changes.
7A5	6CA5	G	Reverse 6CA5 to 7A5 procedure.
7A6	6AL5	G	Parallel circuits only. Change socket to miniature and rewire as follows: Change pin No. 1 to pin No. 3 on miniature to 5
			3 to 2 6 to 7 7 to 1 8 to 4
7AU7	12AT7	G	Same as 7AU7 to 12AU7 procedure.
	12AU7	E	Rewire as follows:
	12AV7	G	Change pin No. 5 to pin No. 9 Same as 7AU7 to 12AU7 procedure.
7C7	6BR7 6BS7	G G	Reverse 6BR7 to 7C7 procedure. Reverse 6BS7 to 7C7 procedure.
7F8	7F8W	E	No changes.
7Z4	6BW4	E	Reverse 6BW4 to 7Z4 procedure.

8AU8-12AQ5 THIRD SUPPLEMENT - RECEIVING TUBE SUBSTITUTION GUIDE

TUBE	SUB. P	ERF.	CIRCUIT CHANGES NECESSARY
8AU8	8AW8 8BA8 8BH8	G G	No changes. No changes. No changes.
8AW8	8AU8 6BH8	G G	No changes.
8BA8	8AU8 8AW8	G G	No changes. No changes.
8BH8	8AU8 8AW8	G G	No changes. No changes.
8BN8			No practical substitute.
8CG7	8SN7	G	Same as 6CG7 to 6SN7 procedure.
8CM7	8CS7	G	Rewire as follows: Change pin No. 3 to pin No. 8
			8 to 3
8CN7			No practical substitute.
8CS7	8CM7	G	Same as 8CM7 to 8CS7 procedure.
8SN7	8CG7	G	Same as 6CG7 to 6CSN7 procedure.
9BM5	9BW6	G	Rewire as follows: Change pin No. 1 to pin No. 2 on noval to 3
			3 to 4 4 to 5 5 to 7 6 to 8 7 to 1
9BW6	9BM5	G	Same as 9BM5 to 9BN6 procedure. Tie pin Nos. 3 and 9 together.
12A7			No practical substitute.
12AB5			No practical substitute.
12AC6	12AF6	G	No changes.
12AD6	12AG6	G	No changes.
12AD7	12AX	E	Parallel circuits only. No changes.
	12SL7	G	Parallel circuits only. Change socket to octal and rewire as follows: Change pin No. 1 to pin No. 2 on octal 2 to 1 3 to 3 4 to 8
			5 to 7 6 to 5 7 to 4 8 to 6
12AE6	12AT6 12AV6	G G	No changes. No changes.
12AF6	12AC6	G	No changes.
12AG6	12AD6	G	No changes.
12AJ5			No practical substitute.
12AQ5	12CM6 (Cont.)	E	Reverse 12CM6 to 12AQ5 procedure.
22			

TUBE	SUB.	PERF.	CIRCUIT CHANGES NECESSARY
12AQ5	12V6	E	Change socket to octal and rewire as follows:
(Cont.)			Change pin No. 1 to pin No. 5 on octal to 8
			60 3 to 2
			(0 0) 4 to 7 $(0 0)$
			5 to 3 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0
			7 to 5
12AS5			No practical substitute.
12AT7	12A7WA	E	No changes.
	6060	Ē	No changes.
	6201 6679	E	No changes.
	0019	E	No changes.
12AU7	12AU7WA	E	No changes.
	5814 5963	E G	No changes. No changes.
	6067	E	No changes.
	6189	E	No changes.
	6680	E	No changes.
12AV5	12BQ6	E	Same as 12CU6 to 12AV5 procedure.
	12CU6	E	Same as 12CU6 to 12AV5 procedure.
	12DQ6	E	Same as 12CU6 to 12AV5 procedure.
12AV7	5965	G	No changes.
12AX7	12AD7	E	No changes.
	5751	E	No changes.
	6057 6681	E E	No changes.
	0001	E.	No changes.
12AY7	6072	E	No changes.
12BH7	6350	G	Reverse 6350 to 12BH7 procedure.
12BJ7			No practical substitute.
12BK5	6BK5	E	Parallel circuits only. Install 6-ohm 20-watt resistor in series with
			filament.
12BL6			No practical substitute.
12BQ6	6BQ6	E	Parallel circuits only. Install 6-ohm 20-watt resistor in series with
	12AV5	G	filament. Reverse 12AV5 to 12BQ6 procedure.
	12CH6	Ĕ	No changes.
	12DQ6	E	No changes.
12BR7			No practical substitute.
12BV7	12BY7	E	No changes.
12BW4	6BW4	E	Parallel circuits only. Install 7-ohm 20-watt resistor in series with filament.
	12X4	G	Parallel circuits only. Change socket to miniature and rewire as follows:
			Change pin No. 1 to pin No. 6 on miniature to 3
			600 5 to 4
			$\begin{bmatrix} 0 & 0 \\ 0 & 0 \end{bmatrix}$ 7 to 1
			9 to 7
12BY7	12BV7	E	No changes.
12C5	12CA5	G	No changes.
	(Cont.)	~	AND CHAMBODI

12C5-12CU6 THIRD SUPPLEMENT - RECEIVING TUBE SUBSTITUTION GUIDE

TUBE	SUB.	PERF.	CIRCUIT CHANGES NECESSARY.
12C5 (Cont.)	12L6	G	Change socket to octal and rewire as follows: Change pin No. 1 to pin No. 8 on octal 2 to 5
			3 to 2 4 to 7 5 to 5 6 to 4 7 to 3
12CA5	6CA5	E	Parallel circuits only. Install 5-ohm 20-watt resistor in series with filament.
	12C5 12L6	G G	No changes. Same as 12C5 to 12L6.
12CM6	5CM6	E	Parallel circuits only. Install 14-ohm 20-watt resistor in series with filament.
12CM6	6CM6	E	Parallel circuits only. Install 14-ohm 20-watt resistor in series with filament.
	12AQ5	E	Change socket to miniature and rewire as follows: Change pin No. 1 to pin No. 6 on miniature to 1
			4 to 3 5 to 4 6 to 7 7 to 2 9 to 5
	12V6	E	Change socket to octal and rewire as follows: Change pin No. 1 to pin No. 4 on octal to 5
			4 to 2 5 to 7 6 to 5 7 to 8 9 to 3
12CN5			No practical substitute.
12CR6			No practical substitute.
12CS6	3CS6	E	Parallel circuits only. Install 16-ohm 20-watt resistor in series with filament.
	6CS6	E	Parallel circuits only. Install 21-ohm 20-watt resistor in series with the filament.
	6BY6	G	Parallel circuits only. Install 21-ohm 20-watt resistor in series with filament.
12CT8			No practical substitute.
12CU5	6CU5		Parallel circuits only. Install 5-ohm 20-watt resistor in series with filament.
	12L6	G	Change socket to octal and rewire as follows: Change pin No. 1 to pin No. 8 on octal 2 to 5
			3 to 2 3 to 7 4 to 7 5 to 5 6 to 4 7 to 3
	12W6	G	Same as 12CU5 to 12L6 procedure.
12CU6	12AV5	G	Rewire as follows: Change pin No. 4 to pin No. 8
			District St. 1
	12BQ6 12DQ6	E E	No changes.

TUBE	SUB.	PERF.	CIRCUIT CHANGES NECESSARY
12D4	12AX4	G	No changes.
12DQ6	12AV5 12BQ6 12CU6	G G	Reverse 12AV5 to 12DQ6 procedure. No changes. No changes.
12F8			No practical substitute.
12G4	12H4 12J5	E E	Remove, connect, and tape up any wires on pin No. 2. Change socket to octal and rewire as follows: Change pin No. 1 to pin No. 3 on octal 3 to 2 5 to 3 4 to 7 6 to 5 7 to 8
	14A4	E	Change socket to octal and rewire as follows: Change pin No. 1 to pin No. 2 on octal
			3 to 1 4 to 8 5 to 2 6 to 6 7 to 7
12G8			No practical substitute.
12H4	12G4 12J5	E	No changes. Change to octal and rewire as follows: Change pin No. 1 to pin No. 3 on octal
			3 to 2 5 to 3 4 to 7 6 to 5 7 to 8
	14A4	E	Same as 14A4 to 12G4 procedure.
12J5	12G4 12H4	E E	Reverse 12G4 to 12J5 procedure. Reverse 12H4 to 12J5 procedure.
12 j 8			No practical substitute.
12K5			No practical substitute.
12L6	12W6 1632	E E	No changes.
12R5	12W6	G	Change socket to octal and rewire as follows: Change pin No. 1 to pin No. 8 on octal
			2 to 5 3 to 2 4 to 7 5 to 5 6 to 4 7 to 3
12SL7	2C52	E	Parallel circuits only. No changes.
12SN7	5814	G	Parallel circuits only. Reverse 5814 to 12SN7 procedure.
12U7			No practical substitute.
12V6	12CM6	E	Reverse 12CM6 to 12V6 procedure.
12W6	12L6 12R5 1632	E G E	No changes. Reverse 12R5 to 12W6 procedure. No changes.
12X4	12BW4	E	Reverse 12BW4 to 12Y4 procedure.

14A4-25C5 THIRD SUPPLEMENT - RECEIVING TUBE SUBSTITUTION GUIDE

TUBE	SUB.	PERF.	CIRCUIT CHANGES NECESSARY
14A4	12G4 12H4	E E	Reverse 12G4 to 14A4 procedure. Reverse 12H4 to 14A4 procedure.
15A6			No practical substitute.
15A8			No practical substitute.
16A5			No practical substitute.
17AV5	6AV5	E	Parallel circuits only. Install 8.7-ohm 25-watt resistor in series with filament.
	12AV5	E	Parallel circuits only. Install 7-ohm 10-watt resistor in series with filament.
	17DQ6	E ,	Same as 12CU6 to 12AV5 procedure.
17AX4	6AX4	E	Parallel circuits only. Install 18-ohm 20-watt resistor in series with filament.
	12AX4	E	Parallel circuits only. Install 10-ohm 20-watt resistor in series with filament.
17C5			No practical substitute.
17CA5	6CA5	E	Parallel circuits only. Install 9-ohm 20-watt resistor in series with
	12CA5	E	filament. Parallel circuits only. Install 10-ohm 20-watt resistor in series with filament.
17DQ6	6DQ6	E	Parallel circuits only. Install 9-ohm 20-watt resistor in series with
	12DQ6	E	filament. Parallel circuits only. Install 10-ohm 20-watt resistor in series with
	17AV5	E	filament. Same as 12CU6 to 12AV5 procedure.
17H3			No practical substitute.
17Z3	17AX4	E	Where space permits change socket to octal and rewire as follows: Change pin No. 4 to pin No. 8 on octal
			cap to 3 5 to 7 9 to 5
18A5			No practical substitute.
19AU4	6AU4	E	Parallel circuits only. Install 7-ohm 30-watt resistor in series with
	19X3	G	filament. Parallel circuits only. Change socket to miniature and rewire as follows:
			Change pin No. 3 to pin No. 3 on miniature
			5 to 9 7 to 4 8 to 5
19X3	19AU4	G	Parallel circuits only. Reverse 19AU4 to 19X3 procedure.
19X8			No practical substitute.
21A6			No practical substitute.
25AV5	25CU6 25DQ6	G G	Reverse 25CU6 to 25AV5 procedure. Reverse 25DQ6 to 25AV5 procedure.
25AX4	17AX4	E	Parallel circuits only. Install 18-ohm 10-watt resistor in series with filament.
	25U4 25W4	G G	No changes.
25C5	25CA5 (Cont.)	G	No changes.

TUBE	SUB.	PERF.	CIRCUIT CHANGES NECESSARY
25C5 (Cont.)	25L6	G	Change socket to octal and rewire as follows: Change pin No. 1 to pin No. 8 on octal. 2 to 5
			$\begin{array}{cccccccccccccccccccccccccccccccccccc$
			$\begin{pmatrix} 0 & 0 \end{pmatrix}$ 4 to 7 $\begin{pmatrix} 0 & 0 \end{pmatrix}$
			5 to 5 6 to 4 7 to 3
	25W6	G	Same as 25L6 to 25C5 procedure.
25CA5	25C5	G	No changes.
	25L6 25W6	G G	Same as 25C5 to 25L6 procedure. Same as 25C5 to 25W6 procedure.
25CD6	25DN6	G	No changes.
25CU6	25AV5	G	Rewire as follows:
			Change pin No. 5 to pin No. 1 cap to 5
			600 8 to 3 60
			(a) (b) 4 to 8 (c) (d)
		<u>_</u>	ORIG
	25BQ6 25DQ6	E E	No changes. No changes.
25DN6	25CD6	G	No changes.
25DQ6	25AV5	G	Same as 25CU6 to 25AV5 procedure.
	25BQ6 25CU6	G G	No changes. No changes.
25L6	6046	G	No changes.
25U4	25AX4	E	No changes.
	25W4	Ē	No changes.
25W4	25U4	G	No changes.
25W6	25L6	E	No changes.
000#			
28D7	28D7W 1238	E E	No changes. No changes.
40A1	40B2	G	No changes.
			
40B2	40A1	G	No changes.
50A1			No practical substitute.
50BK5	25BK5	E	Parallel circuits only. Install 84-ohm 20-watt resistor in series
			with filament.
X155	6BC8	G	No changes.
	6BK7 6BQ7	G G	No changes. No changes.
	6BS8	G	No changes.
	6BZ7	Ğ	No changes.
	6BZ8	Ē	No changes.
807	5933	E	No changes.
884	6Q5	G	No changes.
1221	6 J7	G	Rewire as follows: Change socket to octal.
			Change pin No. 1 to pin No. 2 on octal to 3
			(0,0) 3 to 4 $(0,0)$
			5 to 8 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0
			Onits U

1238-5726 THIRD SUPPLEMENT - RECEIVING TUBE SUBSTITUTION GUIDE

TUBE	SUB.	PERF.	CIRCUIT CHANGES NECESSARY
1238	28D7	G	No changes.
1266	OB3	G	No changes.
1621	6F6 6K6 6L6 6V6 5881	G G G E	No changes. Parallel circuits only. No changes.
1622	6F6 6L6 6V6 5881	G E G E	Parallel circuits only. No changes. No changes. Parallel circuits only. No changes. No changes.
1631	6L6	G	Parallel circuits only. Install 7-ohm 20-watt resistor in series with the filament.
1632	12L6 12W6	E E	No changes. No changes.
1633			No practical substitute.
1635	6N7 6Y7	G G	Parallel circuits only. No changes. No changes.
5591	6AK5 5654	G G	No changes. No changes.
5610	6C4	G	No changes.
5633	5634	E	No changes.
5634	5633	E	No changes.
5637	5646	G	Rewire as follows:
			Change pin No. 2 to pin No. 4 $\begin{array}{cccccccccccccccccccccccccccccccccccc$
5638			No practical substitute.
5654	5591 6096	G E	No changes. No changes.
5670	2C51 5670WA	G E	No changes.
5670WA	5670	G	No changes.
5679	6H6	G	Parallel circuits only. Rewire as follows: Change pin No. 1 to pin No. 2
			Change pin No. 1 to pin No. 2 2 to 4 6 to 5 7 to 8 500 500 500 500 500 500 500 5
5692	6180	E	No changes.
5725	6AS6 6AS6W 6187	G E E	No changes. No changes. No changes.
5726	6AL5 6AL5W 6058 6097	G E E G	No changes. No changes. No changes. No changes.

TUBE	SUB. P	ERF.	CIRCUIT CHANGES NECESSARY
5727	2D21 2D21W	G E	No changes.
5732	6K7	G	No changes.
5749	6BA6 6BA6W	G E	No changes. No changes.
5750	6BE6	G	No changes.
5751	12AX7 5751WA 6057	G E G	No changes. No changes. No changes.
5751WA	12AX7 5751 6057	G G G	No changes. No changes. No changes.
5814	12AU7	G	No changes.
	12SN7	G	Parallel circuits only. Change socket to octal. Rewire as follows: Change pin No. 1 to pin No. 2 2 to 1 3 to 3
			4 to 8 5 to 7 6 to 5 7 to 4 8 to 6
	5814WA 6067	E E	No changes. Parallel circuits only. No changes.
5824	6046	G	No changes.
5838	5839	E	Parallel circuits only. No changes.
5839	5838	E	Parallel circuits only. No changes.
5871	6V6 5992	G G	No changes. Parallel circuits only. No changes.
5881	1621 1622 5932	G G G	Parallel circuits only. No changes. No changes. No changes.
5899	5900	E	No changes.
5900	5899	\mathbf{E}	No changes.
5910	1U4	G	No changes.
5915	6BY6	G	No changes.
5930	2A3	G	No changes.
5931	5U4GB	E	No changes.
5932	6L6 5881	G G	No changes. No changes.
5933	807	G	No changes.
5961	6SA7	G	No changes.
5963	12AU7	G	No changes.
5964	6J6	G	No changes.
5965	12AV7	G	No changes.

5992-6113 THIRD SUPPLEMENT - RECEIVING TUBE SUBSTITUTION GUIDE

TUBE	SUB.	PERF.	CIRCUIT CHANGES NECESSARY
5992	6V6 5871	G G	No changes. Parallel circuits only. No changes.
5998	6AS7	G	Parallel circuits only. No changes.
6005	6AQ5 6AQ5W 6095	G E E	No changes. No changes. No changes.
6006	6SG7	G	No changes.
6046	25L6 5824	G G	No changes. No changes.
6057	12AX7 5751	G G	No changes. No changes.
6058	6AL5 5726	G G	No changes. No changes.
6059	6J7	G	Parallel circuits only. Change socket to octal and rewire as follows: Change pin No. 2 to cap on octal 3 to pin No. 8 4 to 2 5 to 7 7 to 3 8 to 4 9 to 5 sub
6060	12AT7 6201	G G	No changes.
6061	6V6	G	Change socket to octal and rewire as follows: Change pin No. 1 to pin No. 5 on octal 2 to 5 3 to 8 4 to 2 5 to 7 7 to 3 8 to 4
6063	6X4	G	No changes.
6064	6AM6	G	No changes.
6065	6BH6	G G	Parallel circuits only. Rewire as follows: Change pin No. 6 to pin No. 7 7 to 6
6066	6AT6	G	No changes.
6067	12AU7 5814	G E	No changes. Parallel circuits only. No changes.
6072	12AY7	G	No changes.
6080	6AS7	G	No changes.
6095	6AQ5 6AQ5W 6005	G E E	No changes. No changes. No changes.
6096	6AK5 5654	E G	No changes. No changes.
6097	6AL5 5726	G G	No changes. No changes.
6101	6 J6	G	No changes.
6113	6SL7	G	No changes.

TUBE	SUB.	PERF.	CIRCUIT CHANGES NECESSARY
6132	6СН6	G	No changes.
6134	6AC7	G	No changes.
6135	6C4	G	No changes.
6136	6AU6	G	No changes.
6137	6SK7	G	No changes.
6180	6SN7 5692	G E	No changes. No changes.
6186	6AG5	G	No changes.
6187	6AS6 6AS6W 5725	G E E	No changes. No changes. No changes.
6189	12AU7 12AU7WA	G E	No changes.
6201	12AT7 6060	G G	No changes.
6202	6X4	G	No changes.
6265	6BH6	G	No changes.
6350	12BH7	G	Rewire as follows:
			Change pin No. 2 to pin No. 3 to 2 7 to 8
			8 to 7
6485	6AH6	G	
6485 6550	6AH6 6L6	G G	8 to 7
			No changes.
6550	6L6	G	No changes.
6550 6661	6L6 6BH6	G G	No changes. No changes. No changes.
6550 6661 6662	6L6 6BH6 6BJ6	G G G	No changes. No changes. No changes. No changes.
6550 6661 6662 6663	6L6 6BH6 6BJ6 6AL5	G G G	No changes. No changes. No changes. No changes. No changes.
6550 6661 6662 6663 6669	6L6 6BH6 6BJ6 6AL5 6AQ5	G G G G	No changes. No changes. No changes. No changes. No changes. No changes.
6550 6661 6662 6663 6669 6677	6L6 6BH6 6BJ6 6AL5 6AQ5 6CL6	G G G G	No changes.
6550 6661 6662 6663 6669 6677 6679	6L6 6BH6 6BJ6 6AL5 6AQ5 6CL6 12AT7	G G G G G	No changes.



SUBSTITUTING PICTURE TUBES IN TV RECEIVERS

1. Connecting the External Conductive Tube Coating to Chassis

When a picture tube that does not have an external conductive coating is substituted for one that has the external coating, it is generally necessary to install a metal finger to make contact with the coating in order to connect it to the chassis. Sometimes this finger is attached to the deflection yoke support bracket. Ordinarily a tube that does not have an external coating has a 500- $\mu\mu$ f capacitor connected from the anode lead to the chassis inside the high-voltage cage. It is normally not necessary to remove this capacitor when substituting a tube that has the external conductive coating.

2. Installing a Capacitor from the Anode Lead to the Chassis

When a tube that does not have the external conductive coating is substituted for one that has the external conductive coating, it is often necessary to install a capacitor from the anode lead to the chassis. In the substitutions listed here we have repeated the same value of $500~\mu\mu f$. Ordinarily this will be satisfactory. In some cases this capacitor will not be necessary. In others best satisfaction may be had with capacitances as high

as 2,000 $\mu\mu$ f. This is according to individual cases and can be determined by trial. The most convenient location for this capacitor is inside the high-voltage cage.

3. Dimensions

Before attempting any of the substitutions listed here, make sure the substitute tube will fit into the available space. In the magnetic types try to choose a substitute with a neck length similar to the original. Differences in face plate curvatures may make it necessary, in some substitutions listed, to change the mask.

4. Change in Anode Connector

Either the ball-type or cavity-type anode connector is used on picture tubes. Instructions specify when a change is necessary.

5. Replacement or Deletion of Ion Trap

It is necessary to replace the ion trap with the type required by the manufacturer of the substitute tube. Some tubes do not require an ion trap and are being substituted for others requiring either a single or dual ion trap. In these cases, the instruction is "Remove ion trap." Other tubes requiring a single ion trap can be substituted for by installing a dual ion trap and vice versa. In these cases instructions are given. Some manufacturers of picture tubes are using a new type gun requiring a single ion trap in tubes that formerly used a gun requiring a dual ion trap. It is therefore important to check the individual manufacturer's specification on the substitute tube being used.

6. Electrostatic and Self-Focus Tubes

When using electrostatic or self-focus tubes as substitutions for magnetically focused tubes. it is necessary to remove the focus coil from the neck of the tube and replace it with a magnetic centering device. The focus coil may be left in the receiver circuit-wise, in which case it should be mounted in the cabinet in some position where its magnetic field has no effect on the picture. It may be replaced with a choke or resistor. The picture tube socket may have to be changed when it is necessary to bring out a lead from the focus electrode on the picture tube base except in the case of self-focus or automatic focus types. This lead should be connected to a d-c voltage point in the set which gives best focus. The voltage required normally lies between 50 and 350 volts. Self-focus or automatic focus tubes have a special gun structure within the neck of the tube designed

to focus the tube automatically without the use of an external focus voltage.

7. Substituting Electrostatic or Automatic Focus Types with Magnetic Types

When replacing electrostatic focus types with magnetic focus types, discard the magnetic centering device and install a permanent magnet focusing device. This must be mounted on the yoke support with suitable metal brackets. It is practical to replace an electrostatic focus tube using high-focus voltage with a type using low-focus voltage or a self-focus type. When doing this, it is desirable to remove the focus voltage rectifier as a safety measure.

8. Differences in the Face Plate

Differences in the face plate of the tube have little effect on whether or not they may be substituted. Dark-faced tubes give better contrast than white-faced tubes. Some tubes are frosted to decrease reflections and others have an aluminized back for better contrast and brightness. Aluminized tubes in some cases have higher anode voltage applied and this voltage should be reduced in accordance with manufacturers' specifications when other than aluminized tubes are substituted. When substituting aluminized tubes for white- or gray-faced tubes, sufficient voltage is usually available for satisfactory operation.

PICTURE TUBE SUBSTITUTIONS

		HOLE TOPE SOPSILIONOMS
TUBE	SUB.	CHANGES NECESSARY
7CP4	7DP4	Change anode connector to cavity type. Connect external conductive coating to chassis. Change ion trap to double.
7DP4	7CP4	Connect a 500- $\mu\mu$ f 20-kv capacitor from anode to chassis. Change anode connector to ball type. Remove ion trap.
12KP4	12ZP4 12ZP4A	Install single ion trap. Install single ion trap.
12LP4	12ZP4 12ZP4A	Install single ion trap. Install single ion trap.
12QP4	12ZP4	Change anode connector to cavity type. Connect external conductive
	12ZP4A	coating to chassis. Change anode connector to cavity type. Connect external conductive coating to chassis.
12TP4	12ZP4	Connect external conductive coating to chassis. Change ion trap to single.
12ZP4	12KP4 12KP4A 12LP4 12LP4A	Remove ion trap. Remove ion trap. Only where 1-1/8 inch greater length is available. Change ion trap to double. Same as for 12LP4.
	12QP4	Connect a 500-µµf 20-ky capacitor from anode to chassis. Change
	12QP4A 12TP4	annode connector to ball type. Same as for 12QP4. Only where 1-1/8 inch greater length is available. Connect a 500-unf
	12ZP4A	20-ky capacitor from anode to chassis. Change ion trap to double. No changes.
14HP4	14QP4	No changes.
14QP4	14HP4	No changes.
16AEP4	16ABP4	No changes.
17ATP4	17AVP4 17AVP4A	No changes.
17AVP4	17ATP4 17ATP4A	No changes.
17QP4	17YP4	No changes.
17YP4	17QP4 17QP4A	No changes.
20HP4	20HP4D 20LP4 20MP4	No changes. No changes. No changes.
20LP4	20HP4A 20HP4D 20MP4	No changes. No changes. No changes.
20MP4	20HP4A 20HP4D 20LP4	No changes. No changes. No changes.
21ACP4	21ACP4A 21AMP4 21AMP4A 21AQP4 21AQP4A 21BSP4	No changes. No changes. No changes. No changes. Connect a 500- $\mu\mu$ f 20-kv capacitor from anode to chassis. Same as for 21AQP4. No changes.
21AFP4	21ASP4 (Cont.)	No changes.

TUBE	SUB.	CHANGES NECESSARY
21AFP4	21YP4	
(Cont.)	211P4 21YP4A	Connect external conductive coating to ground. Connect external conductive coating to ground.
21ALP4	21ALP4A	No changes.
	21ALP4B	No changes.
	21ANP4 21ANP4A	Connect a 500- $\mu\mu$ f 20-kv capacitor from anode to chassis. No changes.
	21ANP4A 21ATP4	No changes.
	21ATP4A	No changes.
21AMP4	21ACP4	No changes.
	21ACP4A	No changes.
	21AMP4A	No changes.
	21AQP4 21AQP4A	Connect a 500- $\mu\mu$ f 20-kv capacitor from anode to chassis. No changes.
21AMP4A	21ACP4	No changes.
	21ACP4A	No changes.
	21AMP4	No changes.
	21AQP4	Connect a 500- $\mu\mu$ f 20-kv capacitor from anode to chassis.
21ANP4	21ALP4	Connect external conductive coating to chassis.
	21ALP4A 21ALP4B	Connect external conductive coating to chassis.
	21ATP4	Connect external conductive coating to chassis. Connect external conductive coating to chassis.
21AP4	21ZP4	This substitute to be used only when changing from metal to glass
		picture tube. Mask opening must be enlarged. Change anode con-
	01770470	nector to cavity type.
	21ZP4B	Same as 21AP4 to 21ZP4. Connect external conductive coating to chassis.
21AQP4	21ACP4	Connect external conductive coefficients shared
ZIMQI I	21ACP4A	Connect external conductive coating to chassis. Connect external conductive coating to chassis.
	21AMP4	Connect external conductive coating to chassis.
	21AMP4A	Connect external conductive coating to chassis.
	21AQP4A	No changes.
21AQP4A	21ACP4	Connect external conductive coating to chassis.
	21ACP4A	Connect external conductive coating to chassis.
	21AMP4	Connect external conductive coating to chassis.
	21AMP4A 21AQP4	Connect external conductive coating to chassis. No changes.
01 4 7 7 4		
21ARP4	21ARP4A	No changes.
	21JP4 21JP4A	No changes.
	210F4A	No changes.
21ARP4A	21ARP4	No changes.
	21JP4	No changes.
	21JP4A	No changes.
21ASP4	21AYP4	Connect external conductive coating to chassis.
	21XP4	Connect external conductive coating to chassis.
	21XP4A	Connect external conductive coating to chassis.
	21YP4	Connect external conductive coating to chassis.
	21YP4A	Connect external conductive coating to chassis.
21ATP4	21ALP4	No changes.
	21ALP4A	No changes.
	21ALP4B	No changes.
	21ANP4 21ANP4A	Connect a 500-μμf 20-ky capacitor from anode to chassis.
	21ATP4A	Connect a 500- $\mu\mu$ f 20-kv capacitor from anode to chassis. No changes.
21ATP4A	21ALP4	
	21ALP4A	No changes.
	21ALP4B	No changes.
	21ANP4	Connect a 500-µµf 20-kv capacitor from anode to chassis.
	21ANP4A	Connect a 500-\mu f 20-kv capacitor from anode to chassis.
	21ATP4	No changes.

21AUP4-21YP4A THIRD SUPPLEMENT - RECEIVING TUBE SUBSTITUTION GUIDE

TUBE	SUB.	CHANGES NECESSARY
21AUP4	21AUP4A 21AUP4B	No changes. No changes.
	21AVP4	No changes.
	21AVP4A 21AVP4B	No changes.
	ZIAVF4D	No changes.
21AUP4A	21AUP4	No changes.
	21AUP4B	No changes.
	21AVP4 21AVP4A	No changes.
	21AVP4B	No changes.
04.4377		
21AUP4B	21AUP4	No changes.
	21AUP4A 21AVP4	No changes. No changes.
	21AVP4A	No changes.
	21AVP4B	No changes.
21AVP4	21AUP4	No changes.
211141 1	21AUP4A	No changes.
	21AUP4B	No changes.
	21AVP4A	No changes.
	21AVP4B	No changes.
21AVP4A	21AUP4	No changes.
	21AUP4A	No changes.
	21AUP4B	No changes.
	21AVP4 21AVP4B	No changes.
	ZIAVF4D	No changes.
21AVP4B	21AUP4	No changes.
	21AUP4A	No changes.
	21AUP4B 21AVP4	No changes. No changes.
	21AVP4A	No changes.
21AYP4	91 ACD4	
21A1F4	21ASP4 21XP4	Connect a 500- $\mu\mu$ f 25-kv capacitor from anode to chassis. No changes,
	21XP4A	No changes.
	21YP4	No changes.
	21YP4A	No changes.
21BSP4	21ACPYA	No changes.
017774		
21JP4	21ARP4	No changes.
	21ARP4A 21JP4A	No changes. No changes.
	2101 111	No changes.
21JP4A	21ARP4	No changes.
•	21ARP4A	No changes.
	21JP4	No changes.
21MP4	21YP4	This substitute to be used only when changing from metal to
		glass picture tube. Mask opening must be altered. Change anode
	21YP4A	connector to cavity type. Same as 21MP4 to 21YP4 procedure.
	2111 111	Same as 21M1 4 to 2111 4 procedure.
21XP4	21ASP4	Connect a 500-µµf 25-kv capacitor from anode to chassis.
	21XP4A 21YP4	No changes.
	211P4 21YP4A	No changes. No changes.
	WAA- 1/4	ATO OHIGHEOUS
21XP4A	21ASP4	Connect a 500-µµf 25-kv capacitor from anode to chassis.
	21XP4 21YP4	No changes.
	21YP4 21YP4A	No changes. No changes.
		TO OHMIRODI
21YP4	21YP4A	No changes.
21YP4A	21YP4	No changes.

TUBE	SUB.	CHANGES NECESSARY
24BP4		No practical substitute.
24CP4	24CP4A 24QP4	No changes. No changes.
	24TP4	No changes.
	24VP4	No changes.
	24VP4A 24XP4	No changes. Connect a 500-μμf 25-kv capacitor from anode to chassis.
24DP4	24DP4A	No changes.
	24YP4	No changes.
	24ZP4	No changes.
24QP4	24CP4	No changes.
	24CP4A	No changes.
	24TP4	No changes.
	24VP4 24VP4A	No changes. No changes.
	24XP4	Connect a 500-μμf 25-kv capacitor from anode to chassis.
0.4555.4		
24TP4	24CP4	No changes.
	24CP4A 24QP4	No changes. No changes.
	24VP4	No changes.
	24VP4A	No changes
	24XP4	Connect a 500- $\mu\mu$ f 25-kv capacitor from anode to chassis.
24VP4		
24 V F 4	24CP4 24CP4A	No changes.
	24TP4	No changes.
	24VP4A	No changes.
	24XP4	Connect a 500-µµf 25-kv capacitor from anode to chassis.
24VP4A	24CP4	No changes.
	24CP4A	No changes.
	24TP4	No changes.
	24VP4	No changes.
	24XP4	Connect a 500- $\mu\mu$ f 25-kv capacitor from anode to chassis.
24XP4	24CP4	Connect external conductive coating to chassis.
	24CP4A	Connect external conductive coating to chassis. Connect external conductive coating to chassis.
	24QP4 24TP4	Connect external conductive coating to chassis.
	24VP4	Connect external conductive coating to chassis.
	24VP4A	Connect external conductive coating to chassis.
24YP4	24DP4	No changes.
	24DP4A	No changes.
	24ZP4	No changes.
24ZP4	24DP4	No changes.
	24YP4	No changes.
27AP4		No practical substitute.
27MP4	27EP4	This substitute to be used only when changing from metal
		to glass picture tube. Mask opening may be altered. Change anode connector to cavity type.
27SP4	27UP4	No changes.
27UP4	27SP4	No changes.
30BP4		No practical substitute.

EUROPEAN - AMERICAN TUBE SUBSTITUTION

EUROPEAN	AMERICAN	PERF.	CIRCUIT CHANGES NECESSARY
B36	12SN7	G	No changes.
B65	6SN7	G	No changes.
B152	12AT7	G	No changes.
B309	12AT7	G	No changes.
B319	7AN7	G	No changes.
B329	12AU7	E	No changes.
B719	6AQ8	G	No changes.
D63	6H6	G	No changes.
D77	6AL5	E	No changes.
D152	6AL5	G	No changes.
DA90	1A3	E	No changes.
DAC32	1H5 1LH4	E G	No changes. Reverse 1LH4 to DAC32 procedure.
DAF91	1LD5 1S5 1U5	G E G	Reverse 1LD5 to DAF91 procedure. No changes. Reverse 1U5 to DAF91 procedure.
DAF96	1 AH5	E	No changes.
DC70	6375	G	No changes.
DC80	1E3	E	No changes.
DCC90	3A5	E	No changes.
DD6	6AL5	E	No changes.
DD7	6AL5	G	No changes.
DF33	1LC5 1LN5 1N5	G G E	Reverse 1LC5 to DF33 procedure. Reverse 1LN5 to DF33 procedure. No changes.
DF62	1AD4	E	No changes.
DF91	1T4	E	No changes.
DF92	1L4	G	No changes.
DF96	1AF4 1AJ4	G E	No changes.
DF904	1U4	G	No changes.
DH63	6Q7	G	No changes.
DH77	6AT6	E	No changes.
DH149	7C6	G	No changes.
DK32	1A7 1LA6	E G	No changes. Reverse 1LA6 to DK32 procedure.
DK91	1R5	E	No changes.
DK92	1AC6	E	No changes.

EUROPEAN	AMERICAN	PERF.	CIRCUIT CHANGES NECESSARY
DK96	1AB6	E	No changes.
DL33	3Q5	E	No changes.
DL35	1C5	E	No changes.
DL36	1Q5	E	No changes.
DL91	1S4	G	No changes.
DL92	3S4	E	No changes.
DL93	3A4	E	No changes.
DL94	3Y4	E	No changes.
DL95	3Q4	E	No changes.
DL96	3C4	E	No changes.
DM70	1M3	G	No changes.
DP61	6AK5	· E 4 4	No changes.
DY30	1B3	G	No changes.
DY80	1X2A	G	No changes.
EA76	6489	E	No changes.
EAA91	6AL5	G	No changes.
EABC80	6AK8 6T8	E G	No changes. No changes.
EB34	6H6	E	Parallel circuits only. No changes.
EB91	6AL5	E	No changes.
EBC33	1639	G	No changes.
EBC90	6AT6	E	No changes.
EBC91	6AV6	G	No changes.
EBF80	6N8	E	No changes.
EC70	5718	G	No changes.
EC80	6Q4	E	No changes.
EC81	6R4	E	No changes.
EC90	6C4	E	No changes.
EC91	6AQ4	E	No changes.
EC92	6AB4	E	No changes.
ECC33	6SN7	G	Parallel circuits only. No changes.
ECC35	6SL7	G	Parallel circuits only. No changes.
ECC81	12AT7	E	No changes.
ECC82	12AU7	E	No changes.
ECC83	12AX7	E	No changes.
ECC85	6AQ8	E	No changes.
ECC91	6J6	E	No changes.

ECF82-EL821 THIRD SUPPLEMENT - RECEIVING TUBE SUBSTITUTION GUIDE

EUDODEAN	AMEDICAN	DEDE		
EUROPEAN ECF82	AMERICAN 6U8	PERF. E	CIRCUIT CHANGES NECESSARY No changes.	
ECH35	6E8	E	No changes.	
201100	6P8G	Ē	Parallel circuits only. No changes.	
ECH81	6AJ8	E	No changes.	
ECL80	6AB8	E	No changes.	
ECL82	6BM8	E	No changes.	
EF70	6487	G	No changes.	
EF71	5899	G	No changes.	
EF72	5840	G	No changes.	
EF73	6488	E	No changes.	
EF80	6BX6	E	No changes.	
EF85	6BY7	E	No changes.	
EF86	6267	E	No changes.	
EF91	6AM6	E	No changes.	
EF92	6CQ6	E	No changes.	
EF93	6BA6	E	No changes.	
EF94	6AU6	G	No changes.	
EF95	6AK5	E	No changes.	
EF96	6AG5	G	No changes.	
EH90	6CS6	E	No changes.	
EK90	6BE6	E	No changes.	
EL33	6M6G	E	No changes.	
EL34	6CA7	G	No changes.	
EL37	6L6	E	No changes.	
EL38	5881 6CN6	E	No changes.	
EL70	6373	G	No changes.	
EL81	6CJ6	E	No changes.	
EL83	6CK6	E	No changes.	
EL84	6BQ5	E	No changes.	
EL85	6BN5	E	No changes.	
EL90	6AQ5	E	No changes.	
EL91	6AK6	G	Rewire as follows:	
			Change pin No. 2 to pin No. 7 & 2 to 6	
				Ø
			ONIG	9/
	6AM5	E	No changes.	
EL821	6CH6	G	No changes.	

EUROPEAN	AMERICAN	PERF.	CIRCUIT CHANGES NECESSARY
EM34	6CD7	E	No changes.
EM80	6BR5	E	No changes.
EN91	2D21	E	No changes.
EQ80	6BE7	E	No changes.
EY51	6X2	E	No changes.
EY70	5641	G	No changes.
EY80	6U3	E	No changes.
EY84	6374	E	No changes.
EZ35	6X5	E	No changes.
EZ80	6V4	E	No changes.
EZ81	6BW4	E	No changes.
EZ90	6X4	E	No changes.
GZ30	5Z4	E	No changes.
GZ32	5V4	E	No changes.
GZ34	5U4	G	No changes.
H52	5U4	G	No changes.
H63	6F5	E	No changes.
HBC90	12AT6	\mathbf{E}	No changes.
HBC91	12AV6	G	No changes.
HD14	1H5	G	No changes.
HD30	3B4	E	No changes.
HF93	12BA6	E	No changes.
HF94	12AU6	G	No changes.
HK90	12BE6	E	No changes.
HL90	19AQ5	E	No changes.
HL92	50C5	E	No changes.
HM04	6BE6	E	No changes.
HY90	35W4	E	No changes.
KBC32	1H6	G	Reverse 1H6 to KBC32 procedure.
KF35	1E5	E	No changes.
KK32	1C6 1C7 1D7	G G G	Reverse 1C6 to KK32 procedure. No changes. Parallel circuits only. No changes.
KL35	1F4 1F5	G G	Reverse 1F4 to KL35 procedure. No changes.
KT32	25L6	G	No changes.
KT63	6F6 6J7	G G	No changes.

KT66-SP6 THIRD SUPPLEMENT - RECEIVING TUBE SUBSTITUTION GUIDE

EUROPEAN	AMERICAN	PERF.	CIRCUIT CHA	NGES NECESSARY
KT66	6L6	E	Parallel circuits only.	No changes
KT81	7C5	G	No changes.	
KTW63	6K7	G	No changes.	
L63	6J5	G	No changes.	
L77	6C4	E	No changes.	
LN152	6AB8	G	No changes.	
LZ319	8A8	G	No changes.	
N14	1C5	G	No changes.	
N17	3S4	E	No changes.	
N18	3 Q4	E	No changes.	
N19	3V4	E	No changes.	
N77	6AM5	E	No changes.	
N78	6BJ5	E	No changes.	
N144	6AN5	G	No changes.	
N148	7C5	G	No changes.	
N152	21A6	G	No changes.	
N329	16A5	G	No changes.	
N359	21A6	G	No changes.	
N709	6BQ5	G	No changes.	
PABC80	9AK8	E	No changes.	
PCC84	7AN7	E	No changes.	
PCC85	9AQ8	E	No changes.	
PCF80	8A8 9A8	G E	No changes. No changes.	
PCF82	9U8	E	No changes.	
PL21	2D21	E	No changes.	
PL81	21A6	E	No changes.	
PL82	16A5	E	No changes.	
PL83	15A6	E	No changes.	
PY80	19X3	E	No changes.	
PY81	17Z3	E	No changes.	
PY82	19Y3	E	No changes.	
QQV03-10	6360	G	No changes.	
QQV03-28	6252	G	No changes.	
QV05-25	807	G	No changes.	
SP6	6AM6	E	No changes.	

EUROPEAN	AMERICAN	PERF.	CIRCUIT CHANGES NECESSARY
TD03-10	5861	G	No changes.
U50	5 Y 3	G	No changes.
U52	5U4	G	No changes.
U70	6X5	G ,	No changes.
U78	6X4	E	No changes.
U147	6X5	G	No changes.
U149	7Y4	G	No changes.
U154	19 Y 3	G	No changes.
U319	19Y3	G	No changes.
UF41	12AC5	E	No changes.
UBC41	14L7	E	No changes.
UCH42	14K7	E	No changes.
W17	1T4	E	No changes.
W63	6K7	G	No changes.
W77	6065	E	No changes.
W149	7B7	G	No changes.
W179	6BY7	G	No changes.
X14	1A7	G	No changes.
X17	1R5	E	No changes.
X18	1AC6	E	No changes.
X63	6A8	G	No changes.
X79	6AE8	E	No changes.
X81	7 S7	G	No changes.
X148	757	G	No changes.
Y61	6U5	E	No changes.
Z14	1N5	G	No changes.
Z63	6 J 7	G	No changes.
Z77	6AM6 6064	G E	No changes.
Z152	6BX6	G	No changes.
Z179	6BX6	G	No changes.
ZD17	1 S5	E	No changes.
ZD19	185	G	No changes.
1F3	1 T 4	E	No changes.
1FD9	185	E	No changes.
1P10	3SF	E	No changes.
6A7E	6A7	E	No changes.

6D2-3OL1 THIRD SUPPLEMENT - RECEIVING TUBE SUBSTITUTION GUIDE

EUROPEAN	AMERICAN	PERF.	CIRCUIT CHANGES NECESSARY
6D2	6AL5	G	No changes.
6F12	6AM6	G	No changes.
8D3	6AM6	E	No changes.
30C1	8A8	G	No changes.
30L1	7AN7	G	No changes.

OA2-1C6 AMERICAN — EUROPEAN TUBE SUBSTITUTION

AMERICAN	EUROPEAN	PERF.	CIRCUIT CHANGES NECESSARY
OA2	150C2	E	No changes.
OA4	Z300T	E	No changes.
OB2	108C1	G	No changes.
OD3	150C3	E	No changes.
OE3	85A1	E	No changes.
OG3	85A2	E	No changes.
1A3	DA90	E	No changes.
1A7	DK32 X14	E G	No changes. No changes.
1AB6	DK96	E	No changes.
1AC6	DK92 X18	E E	No changes. No changes.
1AD4	DF62	E	No changes.
1AF4	DF96	G	No changes.
1AH5	DAF96	E	No changes.
1AJ4	DF96	E	No changes.
1B3	DY30	G	No changes.
1C5	DL35 N14	E G	No changes. No changes.
1C6	KK32	G	Rewire as follows. Change socket to six pin. Change Pin No. 1 to pin No. 2
			2 to 3 5 to 4 4 to 5 3 to 6 6 to 7



AMERICAN	EUROPEAN	PERF.	CIRCUIT CHANGES NECESSARY
1C7	KK32	G	No changes.
1D7	KK32	G	Parallel circuits only. No changes.
1E3	DC80	E	No changes.
1E5	KF35	G	No changes.
1F4	KL35	G	Rewire as follows: Change to five pin socket.
			Change pin No. 1 to pin No. 2 2 to 3
			(D) (A) 4 to 4 (D)
1F5	KL35	G	No changes.
1H5	DAC32 HD14	E G	No changes.
1H6	KBC32	G	Rewire as follows: Change pin No. 6 to grid cap.
1L4	DF92	G	No changes.
1LA6	DK32	G	Rewire as follows: Change pin No. 1 to pin No. 2
			2 to 3 5 to 4
			4 to 5 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0
			3 to 6 sub 8 to 7
1LC5	DF33	G G	Rewire as follows:
			Change pin No. 1 to pin No. 2 to 3
			$ \begin{array}{cccccccccccccccccccccccccccccccccccc$
			8 to 7 5 to 7
1LD5	DAF91	G	Rewire as follows:
			Change pin No. 1 to pin No. 1 to 3
	•		$ \begin{array}{cccccccccccccccccccccccccccccccccccc$
			2 to 5 (0 0) 6 to 6 8 to 7
1LH4	DAC32	G	Rewire as follows:
			Change pin No. 1 to pin No. 2 to 3
	1		4 to 5 (0.00) 6 to Cap (0.00)
			8 to 7
1LN5	DF33	G	Rewire as follows: Change pin No. 1 to pin No. 2
			2 to 3 3 to 4
			6 to Cap (5) (5) (6) (7) (7)
11/0	DM70		Substitute of the substitute o
1M3	DM70	G	No changes.
1N5	DF33 Z14	E G	No changes. No changes.
1Q5	DL36	E	No changes.

1R5-6AG5

THIRD SUPPLEMENT - RECEIVING TUBE SUBSTITUTION GUIDE

AMERICAN	EUROPEAN	PERF.	CIRCUIT CHANGES NECESSARY
1R5	DK91 X17	E E	No changes. No changes.
1S4	DL91	G	No changes.
185	DAF91 ZD17 ZD19 1FD9	E E G E	No changes. No changes. No changes. No changes.
1T4	DF91 W17 1F3	E E E	No changes. No changes. No changes.
1U4	DF904	G	No changes.
1U5	DAF91	G	Rewire as follows:
			Change pin No. 4 to pin No. 3 to 4 2 to 5 6 to 6
1X2A	DY80	G	No changes.
2D21	EN91 PL21	E E	No changes.
3A4	DL93	E	No changes.
3A5	DCC90 DL99	E G	No changes.
3B4	HD30	E	No changes.
3C4	DL96	E	No changes.
3Q4	DL95 N18	E	No changes.
3Q5	DL33	Е	No changes.
3S4	DL92 N17 1P10	E E E	No changes. No changes. No changes.
3V4	DL94 N19	E E	No changes. No changes.
5U4	GZ34 H52 U52	G G G	No changes. No changes. No changes.
5V4	GZ32	E	No changes.
5Y3	U50	G	No changes.
5Z4	GZ30	E	No changes.
6A7	6A7E	E	No changes.
6A8	X63	G	No changes.
6AB4	EC92	E	No changes.
6AB8	ECL80 SN152	E G	No changes. No changes.
6AE8	X79	E	No changes.
6AG5	EF96	G	No changes.

AMERICAN	EUROPEAN	PERF.	CIRCUIT CHANGES NECESSARY
6AJ8	ECH81 DP61	E E	No changes.
6AK5	EF95	E	No changes.
6AK6	EL91	G	Reverse EL91 to 6AK6 procedure.
6AK8	EABC80	E	No changes.
6AL5	D77 DD6 DD7 D152 EAA91 EB91 6D2	E E G G E G	No changes.
6AM5	EL91 N77 N144	E E G	No changes. No changes. No changes.
6AM6	EF91 SP6 Z77 6F12 8D3	E E G G E	No changes. No changes. No changes. No changes. No changes.
6AQ4	EC91	E	No changes.
6AQ5	EL90	E	No changes.
6AQ8	B719 ECC85	G E	No changes. No changes.
6AT6	DH77 EBC90	E E	No changes. No changes.
6AU6	EF94	G	No changes.
6AV6	EBC91	G	No changes.
6BA6	EF93 HMO4	E E	No changes. No changes.
6BE6	EK90	E	No changes.
6BE7	EQ80	E	No changes.
6BJ5	N78	E	No changes.
6BM8	ECL82	E	No changes.
6BN5	EL85	E	No changes.
6BQ5	EL84 N709	E G	No changes. No changes.
6BR5	EM80	E	No changes.
6BW4	EZ81	E	No changes.
6BX6	EF80 Z152 Z179	E G G	No changes. No changes. No changes.
6BY7	EF85 W179	E G	No changes. No changes.
6C4	EC90 L77	E E	No changes. No changes.
6CA7	EL34	G	No changes.

6CD7-6X5 THIRD SUPPLEMENT - RECEIVING TUBE SUBSTITUTION GUIDE

AMERICAN	EUROPEAN I	PERF.	CIRCUIT CHANGES NECESSARY
6CD7	EM34	E	No changes.
6CH6	EL821	G	No changes.
6CJ6	EL81	E	No changes.
6CK6	EL83	G	No changes.
6CN6	EL38	E	No changes.
6CQ6	EF92	E	No changes.
6CS6	EH90	E	No changes.
6E8	ECH35	E	No changes.
6F5	H63	E	No changes.
6F6	KT63	G	No changes.
6H6	EB34 D63	E G	Parallel circuits only. No changes. No changes.
6J5	L63	G	No changes.
6 J6	ECC91	E	No changes.
6J7	KT63 Z63	G G	No changes.
6K7	KTW63 W63	G G	No changes.
6L6	EL37 KT66	E E	No changes. Parallel circuits only. No changes.
6M6G	EL33	E	No changes.
6N8	EBF80	E	No changes.
6P8G	ECH35	E	Parallel circuits only. No changes.
6Q4	EC80	$\mathbf{E}_{\mathbf{q}}$	No changes.
6Q7	DH63	G	No changes.
6R4	EC81	E	No changes.
6SL7	ECC35	G	Parallel circuits only. No changes.
6SN7	B65 ECC33	G G	No changes. Parallel circuits only. No changes.
6T8	EABC80	G	No changes.
6U3	EY80	E	No changes.
6U5	Y61	E	No changes.
6U8	ECF82	E	No changes.
6V4	EZ80	E	No changes.
6X2	EY51	E	No changes.
6X4	EZ90 U78	E E	No changes.
6X5	EZ35 U147 U70	E G G	No changes. No changes. No changes.

AMERICAN	EUROPEAN I	PERF.	CIRCUIT CHANGES NECESSARY
7AN7	B319 PCC84 30L1	G E G	No changes. No changes. No changes.
7B7	W149	G	No changes.
7C5	KT81 N148	G G	No changes.
7C6	DH149	G	No changes.
757	X81 X148	G G	No changes. No changes.
7Y4	U149	G	No changes.
8A8	LZ319	G	No changes.
	PCF80	G	No changes.
	30C1	G ,	No changes.
9A8	PCF80	E	No changes.
9AK8	PABC80	E	No changes.
9AQ8	PCC85	E	No changes.
9U8	PCF82	E	No changes.
12AC5	UF41	E	No changes.
12AT6	HBC90	E	No changes.
12AT7	B152	G	No changes.
	B309 ECC81	G E	No changes. No changes.
	ECCOI	ы	no changes.
12AU6	B329	E	No changes.
	ECC82 HF94	E G	No changes. No changes.
12AV6	HBC91	G	No changes.
12AX7	ECC83	E	No changes.
12BA6	HF93	E	No changes.
12BE6	HK90	E	No changes.
12SN7	B36	G	No changes.
14K7	UCH42	E	No changes.
14L7	UBC41	E	No changes.
15A6	PL83	E	No changes.
1045	370.00	~	
16A5	N329 PL82	G E	No changes. No changes.
17Z3	PY81	E	No changes.
19AQ5	HL90	E	No changes.
19X3	PY80	E	No changes.
19 Y 3	U154	G	No changes.
	U319	G	No changes.
	PY82	E	No changes.
21A6	N152	G	No changes.
	N359 PL81	G E	No changes. No changes.
	- 1101	شه	TIO OTTORIBOD.

25L6-6489 THIRD SUPPLEMENT - RECEIVING TUBE SUBSTITUTION GUIDE

AMERICAN	EUROPEAN	PERF.	CIRCUIT CHANGES NECESSARY
25L6	KT32	G	No changes.
35W4	HY90	E	No changes.
50C5	HL92	E	No changes.
807	QV05-25	G	No changes.
1639	EBC33	G	No changes.
5641	EY70	G	No changes.
5718	EC70	G	No changes.
5840	EF72	G	No changes.
5861	TD03-10	G	No changes.
5899	EF71	G	No changes.
6064	Z77	G	No changes.
6065	W77	G	No changes.
6252	QQV03-28	G	No changes.
6267	EF86	E	No changes.
6360	QQV03-10	G	No changes.
6373	EL70	G	No changes.
6374	EY84	E	No changes.
6375	DC70	G	No changes.
6487	EF70	G	No changes.
6488	EF73	E	No changes.
6489	EA76	E	No changes.

CUMULATIVE INDEX

The following indices contain all the tubes listed in the Receiving Tube Substitution Guidebook, including those given in the First, Second and Third Supplements, for which substitutions are given.

Where (0) precedes the page number, the substitution information is given on the page referred to in the original *Receiving Tube Substitution Guidebook*; where (1) precedes the page number, the substitution information is given on the page referred to in the First Supplement; where (2) precedes the page number, the substitution information is given on the page referred to in the Second Supplement; where (3) precedes the page number, the substitution information is given on the page referred to in the Third Supplement.

Page references to European substitutes for American tubes have been included under the respective American tube numbers, and are asterisked. Page references to American substitutes for European tubes are listed in the European Index.

RECEIVING TUBES

TUBE	PAGE	TUBE	PAGE	TUBE	PAGE
00A	(0)33	1AB5	(0)35	1B3	(0)36
01A	(0)33	1AB6	(3)1, 44*		(1)14, 15 (2)1
0A2	(0)33 (3)44*	1AC5	(0)35 (3)1	1B4	(3)1, 44* (0)36
0A3	(0)33 (1)13	1AC6	(3)1, 44*	1B5	(0)36
0A4	(0)33	1AD4	(0)35 (3)44*	1B7	(0)36, 37
	(3)44*	1AD5	(0)35, 36	1B8	(0)37
0B2	(0)33 (3)44*	1AE4	(0)36 (1)14	1C3	(0)37 (3)1, 2
0B3	(0)33 (3)1	1AE5	(3)1	1C5	(0)37 (1)15
0C3	(0)33	1AF4	(0)36 (3)1, 44*	1C6	(3)44* (0)37
0D3	(0)33 (3)44*	1AF5	(0)36 (1)14		(3)44*
0E3	(3)44*	1AF6	(3)1	1C7	(0)37 (3)45*
0G3	(3)44*	1AG4	(3)1	1C8	(0)37
0Y4	(0)33	1AG5	(3)1	1C21	(0)37
0Z4	(0)33 (1)13, 14	1AH4	(3)1	1D3	(3)2
0Z4A	(0)33	1AH5	(3)1, 44*	1D5	(0)38
1A3	(0)33 (3)44*	1AH6	(3)1	1D5GT 1D7	(2)1 (0)38
1A4	(0)33, 34	1AJ4	(3)1, 44*	101	(3)45*
	(1)14	1AJ5	(3)1	1D8	(0)38
1A5	(0)34 (1)14	1AK4	(3)1	1E3	(3)2, 45*
1A6	(0)34	1AK5	(3)1	1E4	(0)38 (3)2
1A7	(0)34, 35 (1)14 (3)44*	1AX2	(3)1	1E5	(0)38 (3)45*

THIRD SUPPLEMENT_RECEIVING TUBE SUBSTITUTION GUIDE

TUBE	PAGE	TUBE	PAGE	TUBE	PAGE
1E7	(0)38	1LF3	(3)2	1V	(0)47 (1)19
1E8	(0)38	1LG5	(0)43 (1)17	1V2	(0)47
1F4	(0)38 (1)15	1LH4	(0)43	1V5	(0)47
	(3)45*		(1)17, 18 (3)45*	1V6	(3)2
1F5	(0)38 (1)15	1LN5	(0)43, 44		(0)48
	(3)45*	TEMS	(1)18 (3)45*	1W4	(1)19
1F6	(0)38	1M3	(3)2, 45*	1W5	(0)48
1F7	(0)39			1X2	(0)48
1G4	(0)39	1N5	(0)44 (1)18 (3)45*		(1)19, 20 (2)1
1G5	(0)39			1X2A	(1)20 (2)1
	(1)15	1N6	(0)44, 45		(3)46*
1G6	(0)39 (1)15	1P5	(0)45 (1)18	1Y2	(1)20
1114		105	(0)45	1Z2	(0)48
1H4	(0)39 (1)15	1Q5	(1)18		(1)20
1H5	(0)39		(3)45*	2A3	(0)48 (1)20
	(1)15 (3)45*	1Q6	(0)45		(3)2
1H6	(0)39	1R4/1294	(0)45	2A4G	(0)48
1110	(3)45*	1R5	(0)45 (3)46*	2A5	(0)48
1J5	(0)39 (1)16	184	(0)46	2A6	(0)48
1 70		104	(1)18, 19	2A7	(0)48
1J6	(0)39 (1)16		(3)46*	2AF4	(3)2
1L4	(0)39	185	(0)46 (1)19	2B3	(3)2
	(1)16 (3)45*		(3)46*	2B5	(3)2
1L6	(0)40	186	(0)46	2BN4	
TUU	(1)16	1SA6	(0)46		(3)2
1LA4	(0)40		(1)19	2B7S	(0)49
	(1)16	1SB6	(0)46	2B25	(0)49
1LA6	(0)40,41 (3)45*	1T2	(3)2	2C4	(0)49
1LB4	(0)41	1T4	(0)46, 47 (1)19	2C21	(0)49
**************************************	(1)16		(3)46*	2C22	(0)49 (3)3
1LB6	(0)41	1T 5	(0)47 (1)19	2C51	(0)49
1LC5	(0)41, 42 (3)45*	1T6	(0)47		(3)3
1T CC				2C52	(0)49
1LC6	(0)42	1U4	(0)47 (1)19		(3)3
1LD5	(0)42, 43 (3)45*		(3)2, 46*	2CB5	(3)3
1LE3	(0)43	1U5	(0)47 (3)46*	2D21	(0)49 (3)3, 46*
	(1)16, 17 (3)2	1U6	(0)47	2D21W	(3)3

TUBE	PAGE	TUBE	PAGE	TUBE	PAGE
2E5	(0)49	3B7	(0)51	4BK7	(3)5
2E22	(3)3	3B7/1291	(0)51	4BN6	(3)5
2E26	(0)49	3BA6	(3)4	4BQ7	(3)6
2E30	(0)49	3BC5	(3)4	4BS8	(3)6
2E31	(0)49	3BE6	(3)4	4BU8	(3)6
2E32	(0)49	3BN4	(3)4	4BX8	(3)6
2E35	(0)49	3BN6	(3)4	4BZ7	(3)6
2E36	(0)49	3BT6	(3)4	4BZ8	(3)6
2E41	(0)49	3BU8	(3)4	4CB6	(3)6
2E42	(0)49	3BY6	(3)4	4CX7	(3)6
2 G5	(0)49	3BZ6	(3)4	4DT6	(3)7
2G21	(0)50	3C2	(3)4	5A6	(0)53
2G22	(0)50	3C4	(3)4, 46*	5AM8	(3)7
2S/4S	(0)50	3C5	(0)51	5AN8	(3)7
2T4	(3)3		(3)4	5AQ7	(3)7
2V2	(3)3	3C6	(0)51	5AS4	(3)7
2V3	(0)50	3CB6	(3)4	5AS8	(3)7
2W3	(0)50	3CE5	(3)5	5AU4	(3)7
2X2/879	(0)50	3CF6	(3)5	5AV8	(3)7
2Y2	(0)50	3CS6	(3)5	5AW4	(2)1
2Z2/G84	(0)50	3D6/1299	(0)51		(3)7
3A2	(3)3	3DT6	(3)5	5AX4	(0)53 (3)8
3A3	(3)3	3E5	(0)51	5AZ4	(0)53
3A4	(0)50	3E6	(0)51	JAZIT	(2)1 (3)8
944	(3)46*	3LE4	(0)52 (1)21	5B8	(3)8
3A5	(0)50 (3)46*	3LF4	(0)52	5BE8	(3)8
3A8GT		OUL 4	(1)21	5BK7	(3)8
	(0)50	3Q4	(0)52 (3)5, 46*		(3)8
3AF4	(3)3	3 Q5	(0)52, 53	5BR8	
3AL5	(3)3		(3)46*	5BT8	(3)8
3AU6	(3)3	3S4	(0)53 (3)5, 46*	5CG8	(3)8
3AV6	(3)3	3V4	(0)53	5CL8	(3)8
3B2	(3)4		(3)5, 46*	5CM8	(3)8
3B4	(0)50 (3)46*	4A6	(0)53	5 J 6	(3)8
3B 5	(0)50, 51	4BC5	(3)5	5R4GY	(0)53 (2)1
	(1)20	4BC8	(3)5		A War was a second and a second a second and

THIRD SUPPLEMENT-RECEIVING TUBE SUBSTITUTION GUIDE

TUBE	PAGE	TUBE	PAGE	TUBE	PAGE
5 T 4	(0)53 , 54 (2)1	6AB4	(0)57, 58 (2)1	6AJ4	(2)2
5T8	(3) 8 (3)8		(3)46*	6AJ5	(0)61 (2)2
5U4	(0)54	6AB5/6N5	(0)58	6AJ7	(0)62
	(2)1 (3)46*	6AB6	(0)58	6AJ8	(2)2
5U4G	(3)8	6AB7/1853	(0)58	CATZA	(3)47*
5U4GA	(3)8	6AB8 6AC5G	(3)9, 46* (0)58	6AK4 6AK5	(3)9 (0)62
5U4GB	(3)9	6AC5GT	(0)59	A CAND	(1)22 (2)2
5U8	(3)9	6AC6	(0)59		(3)9, 47*
5V3	(3)9	6AC7	(0)59	6AK6	(0)62 (2)3
5V4	(0)54 (2)1	UACI	(3)9		(3)47*
	(3)9, 46*	6AC7/1852	(0)59	6AK7	(0)62
5V6	(3)9	6AD4	(0)59	6AK8	(2)3 (3)47*
5W4	(0)54 (2)1	6AD5	(0)59	6AL5	(0)62
	(3)9	6AD6	(0)59		(1)23 (3)10, 47*
5X3	(0)54	6AD7	(0)60 (1)22	6AL6	(0)62
5X4	(0)54 (2)1	6AD 8 6AE5	(3)9 (0)60		(1)23 (3)10
5X8	(3)9		(1)22	6AL7	(0)62
5 Y 3	(0)55	6AE6	(0)60	6AM4	(2)3
	(2)1 (3)9, 46*	6AE7 6AE8	(3)9 (3)46*	6AM5	(0)62 (2)3
5 Y 4	(0)55 (2)1	6AF4	(2)1		(3)47*
	(3)9	PARO	(3)9	6AM6	(0)62, 63 (3)10, 47*
5 Z 3	(0)55 (2)1	6AF5	(0)60 (1)22	6AM8	(3)10
5 Z 4	(0)56	6AF6	(0)60	6AN4	(2)3
	(2)1 (3)9, 46*	6AF7	(0)60	6AN5	(0)63
6A3	(0)56	6AG5	(0)60	6AN6	(0)63
6A4	(0)56		(1)22 (2)1	6AN7	(0)63
6A4/LA	(0)56	e A Class	(3)9, 46*	6AN8	(3)10
6A5	(0)56	6AG6G	(0)60	6AQ4	(3)10, 47*
6A6	(0)56 (1)21	6AG7 6AH4	(0)60 (2)2	6AQ5	(0)63 (1)23
6A7	(0)56, 57	6AH5	(0)61		(2)3 (3)10, 47*
	(1)21 (3)46*	6AH6	(0)61, 143	6AQ6	(0)63
6A8	(0)57		(2)2 (3)9		(1)23 (3)10
	(1)21, 22 (3)46*	6AH7	(0)61	6AQ7	(0)63

TUBE	PAGE	TUBE	PAGE	TUBE	PAGE
6AQ8	(3)47*	6B8	(0)67	6BK4	(3)13
6AR5	(0)64	6BA5	(0)67	6BK5	(2)4
6AR6	(0)64 (1)23	6BA6	(0)67 (1)24	6BK6	(0)69 (3)13
6AR7	(0)64		(2)3 (3)11,47*	6BK7	(2)4 (3)13
6AR8	(3)10	6BA7	(0)67	6BL4	(3)13
6AS5	(0)64 (2)3	6BA8	(3)12	6BL7	(1)24
6AS6	(0)64	6BC4	(3)12		(2)4
	(3)10	6BC5	(0)67 (1)24	6BM5	(2)4
6AS7	(3)10		(2)3	6BM8	(3)47*
6AS7G	(0)64		(3)12	6BN4	(3)13
6AS8	(3)10	6BC7	(0)68	6BN5	(3)13, 47*
6AT6	(0)64, 65	6BC8	(3)12	6BN6	(0)69
	(3)10, 47*	6BD4A	(3)12	ODINO	(3)13
6AT8	(3)10	6BD5	(0)68	6BN7	(1)24
6AU4	(3)10	6BD6	(0)68 (3)12	6BN8	(3)14
6AU5	(0)65 (1)23			6BQ5	(3)47*
		6BD7	(0)68	6BQ6	(0)69
6AU6	(0)65, 143 (1)24 (3)11, 47*	6BE6	(0)68 (3)12, 47*		(2)4 (3)14
6AU8	(3)11	6BE7	(3)12, 47*	6BQ7	(1)24 (2)4
6AV4	(3)11	6BE8	(3)12		$(3)\overline{14}$
6AV5	(0)65	6BF5	(0)68	6BR5	(3)47*
6AV6	(0)65	6BF6	(0)68	6BR7	(3)14
OAVO	(2)3 (3)11, 47*	6BF7	(0)68	6BR8	(3)14
A 1175		6BG6	(0)68	6BS5	(3)14
6AW7	(0)65		(1)24 (3)12	6BS7	(3)14, 15
6AW8	(3)11	6BG7	(0)68	6BS8	(3)15
6AX4	(1)24 (3)11	6BH5		6BT6	
6AX5	(0)65	6BH6	(3)12, 13	0010	(0)69 (2)4 (3)15
6AX6	(3)11 (0)65, 66	02110	(1)24 (3)13	6BT8	(3)15
	그 그 경기 수 요리 한국에 된 🖠	CDUC			
6AX8	(3)11	6BH8	(3)13	6BU5	(3)15
6AZ8	(3)11	6BJ5	(3)13, 47*	6BU6	(0)69
6B4	(0)66	6BJ6	(0)68, 69 (2)3	6BU8	(3)15
6B5	(0)66		(3)13	6BV7	(3)15
6B6	(0)66	6B J 7	(3)13	6BV8	(3)15
6B7	(0)67	6BJ8	(3)13	6BW4	(3)15, 47*

THIRD SUPPLEMENT_RECEIVING TUBE SUBSTITUTION GUIDE

PAGE	TUBE	PAGE	TUBE	PAGE
(2)4	6CG8	(3)17	6DN6	(3)20
(3)15	6CH6	(2)6	6DQ6	(3)20
(3)16		(3)17, 48*	6DT6	(3)20
(2)4	6CH7	(3)17	6E5	(0)73
	6CH8	(3)17	6E6	(0)73
	6CJ6	(3)18, 48*		(1)25
	6CK6	(2)6	6E7	(0)73
(2)4	OCT O		6E8	(0)73 (3)48*
(3)16	9CT9	(2)6, 7 (3)18	6F4	(0)73
(2)5	6CL8	(3)18		(0)73, 74
	6CM6	(3)18	02 0	(3)48*
	6CM7	(3)18	6F6	(0)74, 143
	6CM8	(3)18		(1)25 (3)20,48*
(2)5 (3)16			6F7	(0)74
				(1)25
			6F'8	(0)74 (1)25
(2)5			6G5	(0)75
				(See 6U5)
(1)24				(0)75
and the first of the second	0033	(3)10	6H4	(0)75
(3)16	ecca	(9)7	6H5	(0)75
(0)71	6C\$6	(3)19,48*	6H6	(0)75 (3)20, 48*
(0)71, 72	6CS7	(3)19	6H8	(0)75
(3)16	6CU5	(3)19	6J4	(0)75, 76
(3)17, 47*	6CU6	(2)7		(3)20
(3)17		(3)19	6 J 5	(0)76 (1)25
(0)72	6CX7	(3)19		(2)7 (3)20, 48*
(1)25 (2)5	6D4	(0)72	6 J6	(0)76
(3)17	6D6	(0)72		(1)26 (3)20, 48*
(0)72 (1)25	6D7	(0)72	6 J7	(0)76, 77, 143
(3)17	6D8	(0)72		(3)20, 48*
(3)17, 48*	6DA6	(3)19	6 J 8	(0)77, 78 (1)26
(3) 17	6DB6	(3)20	6K4	(0)78
(2)6	6DC6	(3)20		(0)78
(1)25	6DE6	(3)20		
(4)0, 0	6DG6	(3)20	0.40	(0)78, 79 (1)26
	(2)4 (3)15 (3)16 (2)4 (3)16, 47* (2)4 (3)16 (0)69 (2)4 (3)16 (2)5 (3)47* (3)16 (3)16 (2)5 (3)16 (3)16 (0)69, 70 (2)5 (3)16, 47* (0)70 (1)24 (2)5 (0)70, 71, 143 (3)16 (0)71 (0)71, 72 (3)16 (3)17, 47* (3)17 (0)72 (1)25 (2)5 (3)17 (0)72 (1)25 (2)5 (3)17 (0)72 (1)25 (3)17 (2)6	(2)4 6CG8 (3)15 6CH6 (3)16 (2)4 6CH7 (3)16, 47* 6CH8 (2)4 6CJ6 (3)16 6CK6 (0)69 (2)4 6CL6 (3)16 6CM6 (3)16 6CM7 (3)16 6CM8 (3)16 6CM8 (3)16 6CM8 (3)16 6CN7 (0)69, 70 6CQ6 (2)5 (3)16, 47* 6CQ7 (0)70 6CR6 (1)24 (2)5 6CS5 (0)70, 71, 143 (3)16 6CV5 (3)17, 47* 6CU6 (3)17, 47* 6CU6 (3)17, 47* 6CU6 (3)17 6CX7 (0)72 (1)25 6D4 (2)5 (3)17, 48* 6DA6 (3) 17 6DB6 (2)6 6DC6 (1)25 6DE6	(2)4 6CG8 (3)17 (3)15 6CH6 (2)6 (3)17, 48* (3)16 (2)4 6CH7 (3)17 (2)4 6CH8 (3)17 (2)4 6CJ6 (3)18, 48* (3)16 6CK6 (2)6 (3)48* (3)16 6CK6 (2)6, 7 (3)18 (2)4 6CL6 (2)6, 7 (3)18 (2)5 6CL8 (3)18 (3)16 6CM7 (3)18 (3)16 6CM7 (3)18 (3)16 6CM7 (3)18 (3)16 6CM8 (3)18 (3)16 6CM7 (3)18 (3)16 6CM8 (3)18 (3)16 6CM6 (3)18, 48* (3)16 6CN7 (3)18 (0)69, 70 6CQ6 (3)48* (2)5 (3)16, 47* 6CQ7 (3)18 (0)70 6CR6 (3)18 (0)70 6CR6 (3)18 (0)70, 71, 143 (3)16 6CU5 (3)19 (3)17, 47* 6CU6 (2)7 (3)17 (3)19 (3)17 6CX7 (3)19 (0)72 (1)25 6D4 (0)72 (1)25 (3)17 6D6 (0)72 (1)25 (3)17 6D8 (0)72 (3)17, 48* 6DA6 (3)19 (3)17, 48* 6DA6 (3)19 (3)17, 48* 6DA6 (3)20 (1)25 6DC6 (3)20 (1)25 6DE6 (3)20 (1)25 6DE6 (3)20	(2)4 6CG8 (3)17 6DN6 (3)15 6CH6 (2)6 (3)17, 48* 6DQ6 (3)16 (3)16 (3)17 6E5 (3)16, 47* 6CH8 (3)17 6E6 (3)16 6CK6 (2)6 6E7 (3)16 6CK6 (2)6 6E7 (3)16 6CK6 (2)6, 7 (3)18 6F4 (3)16 (3)18 6F4 (3)16 (3)18 6F5 (3)16 (3)18 6F5 (3)16 6CM7 (3)18 6F5 (3)16 6CM7 (3)18 6F6 (3)16 6CM6 (3)18 6F6 (3)16 6CM7 (3)18 6F6 (3)16 6CM7 (3)18 6F6 (3)16 6CM7 (3)18 6F6 (3)16 6CM7 (3)18 6F8 (3)16 6CM7 (3)18 6G5 (3)17 6CM7 (3)19 6H8 (3)17 47* 6CM6 (2)7 (3)19 6H8 (3)17 6CM7 (3)19 6J5 (3)17 6CM7 (3)19 6J5 (3)17 6CM7 (3)19 6J5 (3)17 6D6 (0)72 6J7 (3)17 6D8 (0)72 6J7 (3)17 6D8 (0)72 6J7 (3)17 6D8 (3)20 6K5 (1)25 6DC6 (3)20 6K5

TUBE	PAGE	TUBE	PAGE	TUBE	PAGE
6K7	(0)79, 80 (3)20, 48*	6R8	(0)83 (1)27	6SU7	(0)91 (3)21
6K8	(0)80 (1)26	6S4	(1)27	6SV7	(0)91
6L4	(0)80	6 S6	(0)84	6SZ7	(0)91
6L5	(0)80 (1)26	6SA7	(0)84 (1)28	6 T 4	(2)8 (3)21
6L6	(0)80, 81	6S7	(0)84 (3)20	6T 5	(0)91
	(1)26, 27 (3)20, 48*	6S8	(1)27	6T6	(0)91
6L7	(0)81	6S8GT	(2)8	6T7	(0)91
6M5	(0)81 (2)7	6SA7	(3)20	6 T 8	(0)91, 143 (1)30 (2)8
	(3)20	6SB7Y	(0)84 (1)28		(3)48*
6M6G	(0)81 (3)48*		(3)20	6U3	(2)8 (3)21, 48*
6M7G	(0)81	6SC7	(0)84, 85 (1)28	6U4	(0)91 (1)30
6M8GT	(0)81	6SD7	(0)85	6U5	(0)91
6N4	(0)81	6SE7	(0)85		(1)30 (3)48*
6N5	(0)81	6SF5	(0)85, 86	6U6	(0)91, 92
6N6	(0)81	6SF7	(0)86		(1)30
6N7	(0)81, 82 (3)20	6SG7	(0)86 (1)28 (3)20	6U7	(0)92 (3)21
6N8	(0)82 (3)48*	6SH7	(0)86	6U8	(1)30 (2)8
6P5	(0)82 (1)27		(1)29 (3)20	6V3	(3)21, 48* (2)9
6P7	(0)82 (1)27	6SJ7	(0)86, 87 (1)29 (3)20	6V4	(3)21 (0)92
6P8G	(0)82	6SK7	(0)87, 88	074	(3)21, 48*
	(3)48*	1 260	(1)29 (3)21	6V5GT	(2)9
6Q4	(2)8 (3)48*	6SL7	(0)88 (1)29	6V6	(0)92, 93 (1)30 (3)21
6Q5	(3)20		(3)21, 48*	6377	(0)93
6Q5G	(0)82	6SN7	(0)88, 89	6V7 6V8	(0)30, 31
6 Q6	(0)82		(1)29	6W2	(3)21
6Q7	(0)82, 83 (1)27 (3)48*	6SQ7	(2)8 (3)21, 48* (0)89, 90	6W4	(0)93
6R4	(0)83		(1)29	OTTE:	(1)31
	(2)8 (3)48*	6SR7	(0)90 (1)30	6W5 6W6	(0)93 (0)93
6R6	(0)83	6SS7	(0)90	*	(1)31 (2)9
6R7	(0)83 (1)27	6ST7	(0)91	6W7	(0)93, 94

THIRD SUPPLEMENT-RECEIVING TUBE SUBSTITUTION GUIDE

TUBE	PAGE	TUBE	PAGE	TUBE	PAGE
6X2	(3) 21, 48*	7 B5	(0)100 (1)32	7 T ?	(0)105, 106
6X4	(0)94 (3)21, 48*	7 B6	(0)100 (1)32	7V7 7W7	(0)106 (0)106
6X5	(0)94, 95 (3)21, 48*	7B7	(0)100, 101	7X6	(0)106
6X6G	(0)95		(1)32 (3)49*	7X7	(0)106
6X8	(1)31 (2)9	7 B8	(0)101 (1)32	7Y4	(0)106 (1)34 (3)49*
6Y3G	(0)95	7C4	(0)101	7Z4	(0)106
6 Y 5	(0)95	7 C5	(0)102 (1)32		(1)34 (3)21
6 Y 6	(0)95		(3)49*	8A8	(3)49*
6 Y 7	(0)96 (3)21	7C6	(0)102 (1)33 (2)40*	8AU8	(3)22
6 Y7 G	(0)144		(3)49*	8AW8	(3)22
6 Z 3	(0)96	7 C7	(0)102, 103 (1)33 (3)21	8BA8	(3)22
6 Z4	(0)96	7D7	(0)103	8BH8	(3)22
6 Z 5	(0)96	7D7 7E5	(0)103	8BN8	(3)22
6 Z 7	(0)96	7E6	(0)103	8CG7	(3)22
6ZY5	(0)96	180	(1)33	8CM7	(3)22
7A4	(0)97 (1)31	7E7	(0)103	8CN7	(3)22
7A5	(0)97	7F7	(0)103	8CS7	(3)22
1210	(3)21	7F8	(0)104	8SN7	(3)22
7A6	(0)97 (3)21		(1)33 (3)21	9A8	(3)49*
7A7	(0)97, 98	7G7	(0)104	9AK8	(3)49*
-40	(1)31, 32	7G7/1232	(0)104	9AQ8	(3)49*
7A8	(0)98 (1)32	7G8	(1)33	9BM5	(3)22
7AB7	(0)98, 99	7H7	(0)104	9BW6	(3)22
7AD7	(0)99	737	(0)104 (1)33	9U8	(3)49*
7AF7	(0)99 (1)32	7 K7	(0)105	10	(0)106
7AG7	(0)99	7L7	(0)105	10Y	(0)106
				12A	(0)106
7AH7 7AJ7	(0)99	7N7	(0)105 (1)33, 34	12A4	(2)9
		7Q7	(0)105	12A5	(0)107
7AK7 7AN7	(0)99 (3)49*	7 R7	(1)34 (0)105	12A6	(0)107 (1)34
7AU7	(3)21		(1)34	12A7	(3)22
7B4	(0)100 (1)32	757	(0)105 (1)34 (3)49*	12A8	(0)107 (1)35

TUBE	PAGE	TUBE	PAGE	TUBE	PAGE
12AB5	(3)22	12AZ7	(1)36	12CU5	(3)24
12AC5	(3)49*	12B4	(2)9	12CU6	(3)24
12AC6	(3)22	12B6M	(0)109	12D4	(3)25
12AD6	(3)22	12B7	(0)109	12DQ6	(3)25
12AD7	(3)22	12B8GT	(0)109	12E5	(0)110
12AE6	(3)22	12BA6	(0)109	12F5	(0)110
12AF6	(3)22		(1)36 (3)49*	12F8	(3)25
12AG6	(3)22	12BA7	(0)109	12G4	(3)25
12AH7	(0)107	12BD6	(0)109	12G7G	(0)110
	(1)35	12BE6	(0)109	12G8	(3)25
12AH8	(2)9		(3)49*	12H4	(3)25
12AJ5	(3)22	12BF6	(0)109	12H6	(0)110
12AK7 12AL5	(2)9 (0)107	12BH7	(0)109 (1)36 (3)23	12J5	(0)110 (3)25
12AQ5	(3)22, 23	12BJ7	(3)23	12J7	(0)110
12AS5	(3)23	12BK5	(3)23	12J8	(3)25
12AT6	(0)108	12BK6	(0)109	12K5	(3)25
121110	(1)35 (2)9	12BL6	(3)23	12K7	(0)110,111
	(3)49*	12BN6	(1)36		(1)36
12AT7	(0)108,143 (1)35	12BQ6	(3)23	12K8	(0)111 (1)36
	(3)23, 49*	12BR7	(3)23	12L6	(3)25
12AU6	(0)108 (3)49*	12BT6	(0)109	12L8	(0)111
12AU7	(0)108	12BU6	(0)110	12Q7	(0)111
12AU ((1)35	12BV7	(3)23		(1)36
10 4 375	(3)23	12BW4	(3)23	12R5	(3)25
12AV5	(3)23	12BY7	(2)9	1258	(2)9
12AV6	(0)108 (3)49*	14 D1	(3)23	12SA7	(0)111, 112
12AV7	(0)108	12BZ7	(2)9		(1)36
	(1)35 (3)23	12C5	(3)23	12SC7	(0)112 (1)36
12AW6	(0)108	12C8	(0)110	12SF5	(0)113
	(1)35	12CA5	(3)24		(1)36
12AX4	(1)36	12CM6	(3)24	12SF7	(0)113
12AX7	(0)108 (1)36	12CN5	(3)24	12SG7	(0)113 (1)37
	(3)23, 49*	12CR6	(3)24	12SH7	(0)113
12AY7	(0)108, 109 (1)36	12CS6	(3)24		(1)37
	(3)23	12CT8	(3)24	12SJ7	(0)113 (1)37

THIRD SUPPLEMENT_RECEIVING TUBE SUBSTITUTION GUIDE

TUBE	PAGE	TUBE	PAGE	TUBE	PAGE
12SK7	(0)113, 114 (1)37	14E7	(0)116, 117	19BG6	(0)118
	(2)10	14F7	(0)117 (1)39	19C8	(0)118 (1)40
12SL7	(0)114 (1)37 (3)25	14F8	(0)117 (1)39	19J6	(2)10
12SN7	(0)114	14H7	(0)117	19T8	(0)118 (1)40
	(1)37 (3)25, 49*	14J7	(0)117 (1)39	19V8	(1)40
12SQ7	(0)114, 115 (1)37	14K7	(3)49*	19X3	(2)10 (3)26, 49*
	(2)10	14L7	(3)49*	19X8	(3) 26
12SR7	(0)115 (1)38	14N7	(0)117 (1)39, 40	19 Y 3	(2)10
12557	(2)10	1407			(3)49*
12SW7	(0)115	14Q7	(0)117 (1)40	20	(0)118
	(1)38	14R7	(0)117	20J8	(0)118
12SX7	(0)115	1487	(0)117	21A6	(3)25, 49*
12SY7	(0)115 (1)38	14V7	(0)117	21A7	(0)118
12U7	(3)25	14W7	(0)117	22	(0)118
12V6	(2)10	14X7	(2)10	24A	(0)118
	(3)25			25A6	(0)118, 119
12W6	(3)25	14Y4	(0)117	25A7	(0)119
12X4	(2)10	15	(0)117, 118	25AC5	(0)119
	(3)25	15A6	(3)26, 49*	25AV5	(0)119
12Z3	(0)115 (1)38	15A8	(3)26		(3)26
12 Z5	(0)115	16A5	(3)26, 49*	25AX4	(3)26
14A4	(0)115	17	(0)118	25B5	(0)119
	(3)26	17AV5	(3)26	25B6	(0)119
14A5	(0)116	17AX4	(3)26	25B8GT	(0)119
14A7	(1)38	17C5	(3)26	25BK5	(2)11
14A7/12B7	(0)116	17CA5	(3)26	25BQ6	(0)119
14AF7	(1)38	17DQ6	(3)26	25C5	(3)26, 27
14AF7/XXD	(0)116	17H3	(3)26	25C6	(0)119
14B6	(0)116	17Z3	(3)26, 49*	25CA5	(3)27
1400	(1)38	18	(0)118	25CD6	(3)27
14B8	(0)116	18A5	(3)26	25CU6	(3)27
14C5	(0)116	19	(0)118	25D8GT	
14C7	(0)116 (1)39	19AQ5	(2)10	25D8G1 25DN6	(0)120 (3)27
14E6	(0)116		(3)49*		
	(1)39	19AU4	(3)26	25DQ6	(3)27

TUBE	PAGE	TUBE	PAGE	TUBE	PAGE
25L6	(0)120 (2)11	34	(0)122 (1)41	50	(0)129
	(3)26, 50*	35A5	(0)122, 123	50A1	(3)27
25N6	(0)120 (1)40	35B5	(0)123	50A5	(0)129 (1)42
25S	(0)120	35C5	(0)123	50AX6	(0)129
25 U4	(3)27	35L6	(0)124 (1)41	50AX6G	(2)12
25W4	(0)120 (3)27	35W4	(0)124 (3)50*	50B5	(0)129 (1)42
25W6	(3)27			50BK5	(3)27
25X6	(0)120	35Y4	(0)124, 125 (1)41	50C5	(0)129
25Y4	(0)120	35Z3	(0)125		(1)42 (3)50*
25Y5	(0)120		(1)41	50C6	(0)129
25Z3	(0)120	35Z4	(0)125 (1)41		(1)42, 43
25Z4	(0)120	35Z5	(0)125, 126	50L6	(0)129 (1)43
25Z5	(0)120, 121	6-50	(1)41, 42	50X6	(0)130
25 Z6	(0)121	35Z6	(0)126	50Y6	(0)130
26	(0)121	35/51	(0)126 (1)41		(1)43
26A6	(0)121 (2)11	36	(0)126	50Y7	(0)130
26A7	(0)121	37	(0)126	50Z6	(0)130
40-4 1	(2)11	38	(0)126	50Z7	(0) 130
26BK6	(0)121	39/44	(0)126	EF50	(0)130
26C6	(0)121	40	(0)126	52	(0)130
26CG6	(2)11	40A1	(3)27	VT52	(0)130
26D6	(0)121 (2)11	40B2	(3)27	53	(0)130
26Z5W	(1)40	40Z5	(1)42	55 550	(0)130
27	(0)121	41	(0)127	55S	(0)130
28D7	(0)122	42	(0)127, 128	56 56AS	(0)131
	(2)12 (3)27	43	(0)128	56AS	(0)131
28D7W	(0)122	45	(0)128 (1)42	56S 57	(0) 131 (0) 131
28Z5	(0)122 (2)12	45Z3	(0)128	J1	(1)43
30	(0)122	45Z5	(0)128	57AS	(0)131
31	(0)122		(1)42	57S	(0)131
32	(0)122	46	(0)128	58	(0)131 (1)43
32L7	(0)122	47	(0)128	58AS	(0)131
		48	(0)129		
33	(0)122 (1)40	49	(0)129	588	(0)131

THIRD SUPPLEMENT_RECEIVING TUBE SUBSTITUTION GUIDE

TUBE	PAGE	TUBE	PAGE	TUBE	PAGE
59	(0)131	485	(0)137	1280	(0)139
70A7	(0)131	807	(1)43, 44	1284	(0)139
70L7	(0)131, 132	964	(3)27, 50*	1291	(0)139
71A	(0)132	864	(0)137	1293	(0)139
	(1)43	884	(3)27	1294	(0)139
7 5	(0)132	950	(0)137	1299	(0)139
7 6	(0)132, 133	954	(0)137	1603	(0)144
77	(0)133	955	(0)138	1611	(0)144
78	(0)133, 134	956	(0)138	1612	(0)139
79	(0)134, 144	957	(0)138	1614	(0)139
80	(0)134	958A	(0)138		(1)44
81	(0)134	959	(0)138	1619	(0) 139
82	(0)134	FM1000	(0)138	1620	(0)139
83	(0)134	1005/CK1005	(0)138	1621	(3)28
. 83V	(0)135	CK1013	(0)138	1622	(3)28
84	(0)135	1201	(0)138	1626	(0)139
84/6Z4	(0)135 (1)43	1 203	(0)138	1629	(0)139
85	(0)135, 136	1204	(0)138	1631	(3)28
85AS	(0)136	1206	(0)138	1632	(3)28
89	(0)136	1221	(0)138 (3)27	1633	(3)28
09	(1)43	1000		1634	(0)139
99V	(0)136	1223	(0)138	1635	(3)28
X99	(0)136	1229	(0)138	1639	(3)50*
X 155	(3)27	1230	(0)138	1644	(0)139
117L7	(0)136	1231	(0)138	1654	(0)139
117L7/M7	(0)136	1232	(0)138	2050	(0)139
117M7	(0)136	1238	(3)28	2051	(0)139
117N7	(0)136, 137	1247	(0)138	5517	(0)139
	(1)43	1265	(0)138	5517/CK1013	(0)140
117P7	(0)137	1266	(0)138 (3)28	5590	(0)140
117Z3	(0)137	1267	(0)138		(2)12
117Z4 117Z6	(0)137 (0)137	1273	(0)138	5591	(0)140 (2)12 (3)28
182B/482B	(0)137	1274	(0)138, 139	5608-A	(0)140
183/483	(0)137	1275	(0)139	5610	(3)28
210T	(0)137	1276	(0)139	5618	(0)140

TUBE	PAGE	TUBE	PAGE	TUBE	PAGE
5633	(3)28	5725	(0)141 (3)28	5901	(0)142
5634	(3)28			5910	(0)142 (3)29
5635	(0)140	5726	(0)141 (3)28	5915	(0)142
5636	(0)140	5727	(3)2 9		(3)29
5637	(3)28	5731	(0)141	5930	(3)29
5638	(3)28	5732	(3)29	5931	(0)142 (3)29
5641	(3)50*	5744	(0)141	5932	(0)142
5642	(1)44	5749	(3)29	0002	(3) 29
5643	(0)140	5750	(3)29	5933	(3)29
5646	(0)140	5751	(3)29	5961	(3)29
5647	(0)140	5751WA	(3)29	5963	(3)29
5654	(0)140	5783	(0)141	5964	(3)29
	(3)28	5784	(0)141	5965	(3)29
5670	(0)140 (2)12	5785	(0)141	5992	(3)30
	(3)28	5787	(0)141	5998	(3)30
5670WA	(3)28	5812	(0)141	6005	(3)30
5672	(0)140	5814	(3)29	6006	(3)30
567 6	(0)140	5823	(0)141	6046	(3)30
5677	(0)140	5824	(0)141	6057	(3)30
5678	(0)140		(3)29	6058	(3)30
5679	(0)140 (3)28	5838	(3)29	6059	(3)30
5686	(0)140	5839	(3)29	6060	(3)30
5687	(0)140	5840	(0)141 (3)50*	6061	(3)30
5691	(0)140	5847	(0)141	6063	(3)30
5692	(0)141	5861	(3)50*	6064	(3)30, 50*
	(3)28	5871	(3)29	6065	(3)30, 50*
5693	(0)141	5879	(0)141	6066	(3)30
5694	(0)141	5881	(1)44	6067	(3)30
5697	(0)141		(3)29	6072	(3)30
5702	(0)141	5896	(0)141	6080	(3)30
5703	(0)141	5897	(0)141	6095	(3)30
5704	(0)141	5898	(0)142	6096	(3)30
5718	(0)141 (3)50*	5899	(0)142 (3)29, 50*	6097	(3)30
5719	(0)141	5900	(0)142	6101	(3)30
5722	(0)141	2900	(3)29	6113	(3)30

THIRD SUPPLEMENT_RECEIVING TUBE SUBSTITUTION GUIDE

TUBE	PAGE	TUBE	PAGE	TUBE	PAGE
6132	(3)31	6360	(3)50*	6680	(3)31
6134	(3)31	6373	(3)50*	6681	(3)31
6135	(3)31	6374	(3)50*	7000	(0)144
6136	(3)31	6375	(3)50*	7700	(3)31
6137	(3)31	6485	(3)31	7700	(0)144
6180	(3)31	6487	(3)50*	9001	(0)142
6186	(3)31	6488	(3)50*	9002	(0)142
6187	(3)31	6489	(3)50*	9003	(0)142
6189	(3)31	6550	(3)31	9004	(0)142
6201	(3)31	6661	(3)31	9005	(0)142
6202	(3)31	6662	(3)31	9006	(0)142
6252	(3)50*	6663	(3)31	KT66	(1)43
6265	(3)31	6669	(3)31	X6030	(0)142
6267	(3)50*	6677	(3)31	XXD	(1)44
6350	(3)31	6679	(3)31	XXFM	(0)142
	\ \ \ \ \ \			XXL	(0)142

PICTURE TUBES

TUBE	PAGE	TUBE	PAGE	TUBE	PAGE	
7CP4	(3)34	10FP4A	(2)15	12TP4	(2)17 (3)34	
7DP4	(3)34	10MP4	(2)15	12UP4	(2)17	
7HP4	(2)15	10MP4A	(2)15	12UP4A	(2)17	
7NP4	(2)15	12JP4	(2)16	12UP4B	(2)17	
7QP4	(2)15	12KP4	(2)16 (3)34	12VP4	(2)17	
7WP4	(2)15	12KP4A	(2)16	12ZP4	(3)34	
8AP4	(2)15			14BP4	(2)18	
8AP4A	(2)15	12LP4	(2)16 (3)34	14BP4A	(2)18	
10BP4	(2)15	12LP4A	(2)16	14CP4	(2)18	
10BP4A	(2)15	12QP4	(2)16, 17 (3)34	14DP4	(2)18	
10CP4	(2)15	12QP4A	(2)16, 17	14EP4	(2)18	
10EP4	(2)15			14FP4	(2)18	
10FP4	(2)15	12RP4	(2)17	14HP4	(3)34	

CUMULATIVE INDEX-PICTURE TUBES

TUBE	PAGE	TUBE	PAGE	TUBE	PAGE
14QP4	(3)34	16YP4	(2)22	19GP4	(2)24
15AP4	(2)18	16ZP4	(2)22	19JP4	(2)24
15CP4	(2)18	17AP4	(2)22	20CP4	(2)24
15DP4	(2)19	17ATP4	(3)34	20CP4A	(2)24
16AEP4	(3)34	17AVP4	(3)34	20CP4C	(2)24, 25
16AP4	(2)19	17BP4	(2)22	20DP4	(2)25
16AP4A	(2)19	17BP4A	(2)22	20DP4A	(2)25
16CP4	(2)19	17BP4B	(2)22	20FP4	(2)25
16DP4	(2)19	17BP4C	(2)22	20GP4	(2)25
16DP4A	(2)19	17CP4	(2)22	20HP4	(2)25
16EP4	(2)19	17CP4A	(2)22		(3)34
16EP4A	(2)19	17FP4	(2)23	20HP4B	(2)25
16EP4B	(2)19	17FP4A	(2)23	20LP4	(3)34
16FP4	(2)19	17HP4	(2)23	20MP4	(3)34
16GP4	(2)19	17HP4A	(2)23	21ACP4	(3)34
16HP4	(2)19	17JP4	(2)23	21AFP4	(3)34, 35
16HP4A	(2)19	17KP4	(2)23	21ALP4	(3)35
16JP4	(2)19, 20	17LP4	(2)23	21AMP4 21AMP4A	(3)35 (3)35
16JP4A	(2)19, 20	17LP4A	(2)23	21ANP4	(3)35
16KP4	(2)20	17QP4	(2)23	21AP4	(3)35
16KP4A	(2)20	11011	(3)34	21AQP4	(3)35
16LP4	(2)20	17RP4	(2)23	21AQP4A	(3)35
16LP4A	(2)20	17SP4	(2)23	21ARP4	(3)35
16MP4	(2)20	17UP4	(2)23	21ARP4A	(3)35
16MP4A	(2)20	17VP4	(2)23	21ASP4	(3)35
16QP4	(2)20	17YP4	(3)34	21ATP4	(3)35
16RP4	(2)20	19AP4	(2)24	21ATP4A	(3)35
16SP4	(2)21	19 AP4 A	(2)24	21AUP4	(3)36
16SP4A	(2)21	19AP4B	(2)24	21AUP4A	(3)36
16TP4	(2)21	19AP4C	(2)24	21AUP4B	(3)36
16UP4	(2)21	19AP4D	(2)24	21AVP4	(3)36
16VP4	(2)21	19DP4	(2)24	21AVP4A	(3)36
16WP4	(2)21	19DP4A	(2)24	21AVP4A 21AVP4B	
16WP4A	(2)21	19EP4	(2)24	21AYP4B	(3)36
16XP4	(2)21	19FP4	(2)24	21A1P4 21BSP4	(3)36 (3)36

THIRD SUPPLEMENT_RECEIVING TUBE SUBSTITUTION GUIDE

TUBE	PAGE	TUBE	PAGE	TUBE	PAGE
21EP4	(2)25	21YP4A	(3)36	24VP4A	(3)37
21EP4A	(2)25	21ZP4	(2)26	24XP4	(3)37
21EP4B	(2)25	21ZP4A	(2)26	24YP4	(3)37
21FP4	(2)25	22AP4	(2)26	24ZP4	(3)37
21FP4A	(2)26	22AP4A	(2)26	27AP4	(3)37
21JP4	(3)36	24AP4	(2)26	27EP4	(2)26
21JP4A	(3)36	24AP4B	(2)26	27GP4	(2)26
21KP4	(2)26	24BP4	(3)37	27MP4	(3)37
21KP4A	(2)26	24CP4	(3)37	27NP4	(2)26
21MP4	(3)36	24DP4	(3)37	27RP4	(2)26
21WP4	(2)26	24QP4	(3)37	27SP4	(3)37
21XP4	(3)36	24TP4	(3)37	27UP4	(3)37
21XP4A	(3)36	24VP4	(3)37	30BP4	(3)37
21YP4	(3)36				

EUROPEAN TUBES

TUBE	PAGE	TUBE	PAGE	TUBE	PAGE
B36	(3)38	DC80	(3)38	DK92	(3)38
B65	(3)38	DCC90	(3)38	DK96	(3)39
B152	(3)38	DD6	(3)38	DL33	(3)39
B309	(3)38	DD7	(3)38	DL35	(3)39
B319	(3)38	DF33	(3)38	DL36	(3)39
B329	(3)38	DF62	(3)38	DL91	(3)39
B719	(3)38	DF91	(3)38	DL92	(3)39
D63	(3)38	DF92	(3)38	DL93	(3)39
D77	(3)38	DF96	(3)38	DL94	(3)39
D152	(3)38	DF904	(3)38	DL95	(3)39
DA90	(3)38	DH63	(3)38	DL96	(3)39
DAC32	(3)38	DH77	(3)38	DM70	(3)39
DAF91	(3)38	DH 149	(3)38	DP61	(3)39
DAF96	(3)38	DK32	(3)38	DY30	(3)39
DC70	(3)38	DK91	(3)38	DY80	(3)39

CUMULATIVE INDEX-EUROPEAN TUBES

TUBE	PAGE	TUBE	PAGE	TUBE	PAGE
EA76	(3)39	EF92	(3)40	Н63	(3)41
EAA91	(3)39	EF93	(3)40	нвс90	(3)41
EABC80	(3)39	EF94	(3)40	HBC91	(3)41
EB34	(3)39	EF95	(3)40	HD14	(3)41
EB91	(3)39	EF96	(3)40	HD30	(3)41
EBC33	(3)39	EH90	(3)40	HF93	(3)41
EBC90	(3)39	EK90	(3)40	HF94	(3)41
EBC91	(3)39	EL33	(3)40	НК90	(3)41
EBF80	(3)39	EL34	(3)40	HL90	(3)41
EC70	(3)39	EL37	(3)40	HL92	(3)41
EC80	(3)39	EL38	(3)40	HM04	(3) 41
EC81	(3)39	EL70	(3)40	HY90	(3)41
EC90	(3)39	EL81	(3)40	KBC32	(3)41
EC91	(3)39	EL83	(3)40	KF35	(3)41
EC92	(3)39	EL84	(3)40	KK32	(3)41
ECC33	(3)39	EL85	(3)40	KL35	(3)41
ECC35	(3)39	EL90	(3)40	KT32	(3)41
ECC81	(3)39	EL91	(3)40	KT63	(3)41
ECC82	(3)39	EL821	(3)40	KT66	(3)42
ECC83	(3)39	EM34	(3)41	KT81	(3)42
ECC85	(3)39	EM80	(3)41	KTW63	(3)42
ECC91	(3)39	EN91	(3)41	L63	(3)42
ECF82	(3)40	EQ80	(3)41	L77	(3)42
ECH35	(3)40	EY51	(3)41	LN 152	(3)42
ECH81	(3)40	EY70	(3)41	LZ319	(3)42
ECL80	(3)40	EY80	(3)41	N14	(3)42
ECL82	(3)40	EY84	(3)41	N 17	(3)42
EF70	(3)40	EZ35	(3)41	N 18	(3)42
EF71	(3)40	EZ80	(3)41	N 19	(3)42
EF72	(3)40	EZ81	(3)41	N77	(3)42
EF73	(3)40	EZ90	(3)41	N78	(3)42
EF80	(3)40	GZ30	(3)41	N 144	(3)42
EF85	(3)40	GZ32	(3)41	N148	(3)42
EF86	(3)40	GZ34	(3)41	N 152	(3)42
EF91	• (3)40	H52	(3)41	N329	(3)42

THIRD SUPPLEMENT-RECEIVING TUBE SUBSTITUTION GUIDE

TUBE	PAGE	TUBE	PAGE	TUBE	PAGE
N359	(3)42	U52	(3)43	X81	(3)43
N709	(3)42	U70	(3)43	X148	(3)43
PABC80	(3)42	U78	(3)43	Y61	(3)43
PCC84	(3)42	U 147	(3)43	Z14	(3)43
PCC85	(3)42	U149	(3)43	Z63	(3)43
PCF80	(3)42	U 154	(3)43	Z77	(3)43
PCF82	(3)42	U319	(3)43	Z152	(3)43
PL21	(3)42	UBC41	(3)43	Z179	(3)43
PL81	(3)42	UCH42	(3)43	ZD17	(3)43
PL82	(3)42	UF41	(3)43	ZD19	(3)43
PL83	(3)42	W17	(3)43	1F3	(3)43
PY80	(3)42	W63	(3)43	1FD9	(3)43
PY81	(3)42	W77	(3)43	1P10	(3)43
PY82	(3)42	W149	(3)43	6A7E	(3)43
QQV03-10	(3)42	W179	(3)43	6D2	(3)44
QQV03-28	(3)42	X14	(3)43	6F12	(3)44
QV05-25	(3)42	X17	(3)43	8D3	(3)44
SP6	(3)42	X 18	(3)43	30C1	(3)44
TD03-10	(3)43	X63	(3)43	30L1	(3)44
U50	(3)43	X79	(3)43		

ADV Plans, LL

Copyright Notice:

The entire contents of this CD/DVD are copyright 2014 by ADV Plans, LLC. All Rights Reserved.

Reproduction or distribution of this disk, either free or for a fee is strictly prohibited. We actively monitor and remove listings on eBay thru Vero.

You are free to copy or use individual images in your own projects, magazines, brochures or other school projects.

Only the sellers listed here are authorized distributors of this collection: www.theclassicarchives.com/authorizedsuppliers

Please view our other products at www.theclassicarchives.com, or our ebay stores:

TheClassicArchives
ADVPlans
SuperShedPlans

